

ProtaStructure 2022

Basic Training Guide

Version 3.0

20 Oct 2022

Please get in touch with us for your training and technical support queries

asiasupport@protasoftware.com

globalsupport@protasoftware.com

Limitation of Responsibilities

Prota shall not be held responsible for any losses caused by documentation, software, or usage errors.

In addition to Prota License Agreement Terms, it is the responsibility of the user

- to check of results generated by documentation and software,
- make sure that the users of the software and their supervisors have adequate technical capabilities,
- make sure that the software is used correctly per the reference manual and documentation,

Intellectual Property

ProtaStructure is a registered trademark of **Prota Software Inc.** All intellectual property rights belong to **Prota Software Inc.** Documentation, training, and reference manuals, and program components can not be copied, distributed, and used in violation of the license agreement.

Trademarks

ProtaStructure®, **ProtaDetails®**, **ProtaSteel®** ve **ProtaBIM®** are registered trademarks of Prota Software Inc. Prota logo is a trademark of Prota Software Inc.

Table of Contents

Introduction	6
User Interface	6
Ribbon User Interface	6
Views	7
Structure Tree Search Option	7
Quick Access Toolbar	7
Display Settings	8
Active Window Settings & Visual Interrogation	8
Layer Toolbars (under Display Tab)	9
Start Page	10
Starting a new project	11
Settings Center	13
Number of Backups to Save	13
Project Template	14
Selection Methods	15
Zoom & Pan Methods	15
Modeling Axes	15
Axis / Grid Tool	16
External Reference Drawing	19
Add	19
Active	19
Unit	19
Storey No	19
Use Colors	20
Opacity	20
Scale Factor	20
Move & Offset	20
Import	20
Orthogonal Axis Generator	21
Columns Creation	22
Walls Creation	24
Beams Creation	25
Beams Creation using dynamic snap points	28

Handy Tip to adjust the position of columns and beams	29
Load Combinations	30
Slab Creation.....	31
Inserting Cantilever Slabs (Type 12).....	33
Polyline Slab/Column Edge	34
Views Creation	35
Inserting Storeys & Defining Building Parameters	36
Wall Loads Library.....	38
Member Load Editor	39
Storey Load Editor	41
Defining Slab Load via Load Editor.....	43
Defining Slab Load (via plan view)	45
Slab Opening Creation	46
Member Re-labelling for Entire Building.....	47
Building Analysis	48
Materials.....	49
Load Combinations	50
Wind and Storey Loads	51
Building Analysis Model Options.....	51
Running Analysis	52
Axial Load Comparison Report.....	53
Analytical Model	54
Column & Wall Design	59
Manually Specifying Column Design Forces (for info).....	62
Manually Change Column Reinforcement (for info)	62
Beam Design	63
Slab Analysis & Design	67
Design Status	71
Quantity Extraction Tables.....	72
Project Preferences	72
Report Manager.....	73
Steel Model.....	74
Axis Creating & Storey Insertion	75
Materials & Load Case / Combination Generator	76
Steel Columns Creation	77
Steel Beams Creation.....	79


Steel Truss Creation	80
Purlins Creation	82
Creating Cladding & Loads	83
Braces Creation.....	84
Girts Creation.....	88
Column Splice Creation.....	89
Building Analysis	89
Steel Design	90
Design Status & Design Utilization	94
Closing Summary	95

Introduction


Thank you for choosing ProtaStructure. This Quick Start Guide aims to get you up and running quickly. You should be able to model, analyze and review the results for this simple model in around 1 hour.

User Interface

ProtaStructure 2022 welcomes you with a modern & efficient user interface designed from scratch for ease of use. The various components of the ProtaStructure user interface are as shown below:




Ribbon User Interface



The ribbon consists of several toolbars placed on various tabs. Each toolbar contains related commands organized into logical & functional groups. Placing the mouse cursor over the command will reveal the Tooltip explaining how to use the function.

Generally, you create the model from the left to right ribbon tab. i.e., start with **Building Setout > Modelling > Loading > Review > Analysis > Design > Drawings & Report**.

Views




Create as many views as you need, such as a plan, 3D physical Model, Analytical Model, and 3D rebars. Views can be organized using smart window layout options.

Customize your work area by docking and floating views. The interface is compatible with multiple monitors. If you want to make the most of your screenscape, just move one of the views to another screen.


Structure Tree Search Option

Are you looking for a specific member or object? Type in the member label in the structure tree's search box and let ProtaStructure find it for you.



Quick Access Toolbar

The Quick Access toolbar displays commonly used commands. Any command can be added to the Quick Access toolbar by right-clicking on the command → **Add to Quick Access Toolbar**.




Display Settings

Colors: Choose the background color and various active modeling objects

Grid: Sets the spacing of the grid system to allow ease of modeling as objects can snap to the intersection of the grids

Object Snap: Choose the various snap options such as Start/End/Corner, Perpendicular or Orthogonal Grid, etc.

Graphics Performance: Options that affect graphics performance. Defaults will give optimal performance.



Active Window Settings & Visual Interrogation


Visual Interrogation: Color-code members to various criteria such as design status, material types, beam with wall loads. It is a vital visual tool to check and verify the inputs and results of the model.

Scene Settings: Control the views' graphics and switch on/off the guiding Grids & Coordinate Axis, etc.

Visibility Filters: Filter to the specific storey, Axis, or member type.

Column Plan Display: The column wall axial, moment & shear forces to be displayed on the plan view.

Beam Plan Display: Allows brick/partition wall label, load value & height to be color-coded and displayed in the plan view. In addition, you can show the total user-defined load (only after the analysis) & display beam elevation marks.




Slab Plan Display: The plan view shows the dead and live load values.

FE Contours: Shows the FE contours exported from the FE Analysis Post-Processing

Animation: Animate by spinning the model in 3D view

















Each modeling window can have separate view settings.

For example, you might want to color the slab live loads on the plan view &, at the same time, color design status in the 3D view.




In the **Scene Settings** tab, the **grid** allows you to switch on/off the grey rectangular grids in the background. **Coordinate Axis** will enable you to switch on/off the coordinate symbol.

Layer Toolbars (under Display Tab)

Layer and color settings		Switch on/off layers and modify the name, color, opacity, line type, line weight, font type, and text height.
Axis Layer Group		switch on/off the axes layer
Column Layer Group		switch on/off the column layer
Wall Layer Group		switch on/off the wall layer
Partition Wall Layer		switch on/off the partition/brick wall layer
Beam Layer Group		switch on/off the beam layer
Slab Layer Group		switch on/off the slab layer
Ribbed Slab Layer Group		switch on/off the ribbed slab layer
Slab Load Layer Group		switch on/off the slab load layer
Slab Strip Layer Group		switch on/off the slab strip layer
Steel Bars Layer		switch on/off the slab reinforcement layer
Steel Member Layer		Switch on/off steel members such as truss, brace, purlins, girts, etc
Ghost Axis Layer Group		switch on/off the ghost axis layer
Plane Definition Layer		switch on/off the plane definition layer
Text Layer Group		switch on/off all the texts
Footing Layer Group		switch on/off the footing layer

Start Page

When the ProtaStructure is launched, the “Start Page” will appear.



The Start Page contains the following functions:

- ❖ Open existing project
- ❖ Start a new project
- ❖ Read Prota **News** and watch Prota **Videos**
- ❖ Access Prota **Resources** such as Help Center, What' New document & Quick Start Guide
- ❖ Read important **Notification** and download new software **Update**
- ❖ View **Subscription** status


You can always open the Start Page by going to the **Help** tab → **Start Page**.

Software update is checked automatically when there is internet connection.

Starting a new project

- Click **Open Project** in the **Start Page** & the **Open Project** dialog will appear.


Here is the explanation of the functions in this dialog :




1. The **Project Data Folder** is the main folder where the project models are stored. The project model consists of several files stored in a single folder called the **Project folder**. This **Project folder** is created as a subfolder in the **Project Data Folder**. The project folder name will always be created precisely the same as the **project name**.
2. A Data Folder called ProtaData2022 would be installed under My Documents by default.
3. If required, you can specify a different location by clicking **Choose/Create Folder**.
4. Clicking on **Explore** will open the current Project Data Folder in windows explorer.
5. You can open existing projects stored in this Data Folder by selecting the project list. After selecting the project, a preview of the project will be shown on the right-hand side. Double-clicking on the project name or clicking **OK** will open the project.
6. Click on the **dropdown** list below to expose the most recent accessed Data Folders.
7. Tick **Most Recently Used Projects** to show the recent projects opened quickly.
8. You can also read **Project Last Saved Date** to locate the saved project quickly.

Previous versions of ProtaStructure model can be opened directly in PS 2022:

- Firstly, you must choose the correct Data Folder by clicking **Choose/Create Folder**.
- Browse to the desired **Data Folder** (note data folder is the main folder, not the project folder)
- You will then be able to see the project and open it.
- You will be prompted to save the model as another name.
- After converting, the project will open.
- Newer version projects can't be opened in older versions of ProtaStructure (not backward)


- Click **New Project**  and type the project name as shown using the ‘_’ character for spaces.
- Select **Singapore (Eurocode)** template




Templates are used to rapidly establish default model parameters such as design codes, material properties, member design settings, etc. Alternatively, you can choose to duplicate settings from an existing project by picking “**Projects**”.

- Click **OK**.


The main modeling area will now show a set of rectangular grids in the background.




By default, these grids spacing is 1m with a major grid colored darker every 5m. The defaults can be changed via the **Display Setting** button 

Settings Center

The **Setting Center** can be accessed by clicking on the **Settings** icon in the **Quick Access Toolbar** or from the **Display tab** (as shown below).



The **Settings Center** centralizes all the program's default settings, including analysis, design and detailing, and Units & format settings.




For example, when you initially start a project, it's advisable to review the **Automatic Save Interval** in the **View & Save** dialog. By default, "0" means it's disabled.

- Change the **Automatic Save Interval** to **10 minutes** to ensure the model is auto-saved.
- Untick **Prompt for Automatic Saving** to set the auto-save to run silently in the background.

Number of Backups to Save


The **Number of Backups to Save** refers to the automatic & silent additional backup created every full hour. For example, the 1st backup file will be created at 9:00 am sharp, 2nd backup at 10:00 & 3rd backup at 11:00. At 12:00 pm, the backup will overwrite the 1st backup, and the cycle continues.

The backup zip files can be found in a folder called "**Backup**" in the same **Project Data Folder**. The files name will have the date and time stamp (example shown below)



Project Template

The available templates are shown when you start a new project, and you must choose one. You can reaccess these templates via the **Building Setout** tab.



Importing an existing Template → refer to step 1,2,3 above

You can change the template of a currently opened project by selecting a different template and **Importing** it :

- Pick a **Template (1)** → Pick **Select All (2)** → **Import (3)**

All the settings of the imported template will apply to the current project.

Exporting a new Template → refer to step A, B, C, D above

You can save the settings of your current project as your template by **Exporting** it :

- Pick **New Template (A)** → Give it a name → **OK** → The new template will be created (**B**)
- **Select** the new template (**B**) → **Select All (C)** → **Export (D)**

The template will be successfully exported & can be re-used the next time you start a new project.

Selection Methods

Selection is performed by placing the mouse cursor on a member or Axis in the modeling view. Although there is no entity to select now, the information is essential as you work through the model.

- *Left-click on the entity to select the entity. Selected entities are also highlighted in the **Structure Tree***
- *To select multiple entities, hold down the **CTRL** key while you pick them*
- *You can select entities directly from the **Structure Tree***

You can drag with the mouse to access further selection options:




- *Drag from **left to right** to create a rectangular box. When you release the mouse button, all entities **wholly contained** within the box will be selected*
- *Drag from **right to left** similarly, and all the entities that **cross its boundaries** will be selected*

If you **right-click** the selected entities, you will see a pop-out **context menu** that allows you to edit and perform other tasks related to that entity, such as Properties, Delete, etc.

Pressing **ESC** will deselect all entities.

Zoom & Pan Methods

The useful functions for zoom are just above the structure tree :

- **Zoom Window**  → Zoom into the area defined by dragging a rectangle.
- **Zoom Previous**  → Zoom to the previous view.
- **Zoom Extents**  → zooms to the selected entities. If no entities are selected, it will zoom to show all entities.

You will find it easiest to use the mouse wheel to:

- **Zoom in** → scroll your mouse wheel **up**
- **Zoom out** → scroll the mouse wheel **down**
- **Pan (move)** → **hold down** the middle mouse wheel and **drag**



Modeling Axes

The very first step to building a model is to define axes. Axes intersections then become the nodes at which members are inserted. Hence, axes must be created correctly. There are three ways to model axes:

1. **Axis toolbar** to build axes individually
2. **External Reference Drawing** to import all axes from the DXF drawing file.
3. **Orthogonal Axis Generator** to create a system of axes quickly


Axis / Grid Tool





Modeling individual axes is simple using the program's Dynamic Input System (DIS).


- Click on **Grid**  in the **Modelling** tab.

There are several insertion methods for the Axis:




 **Single Segment** allows you to create a straight-line axis by clicking on the start and endpoint of the Axis.

 **Multi-segment** axis enables you to create a single axis with multiple segments of any shape


 **Curve Axis** can be created by specifying the radius

- Ensure **Single Segment** insertion is selected
- Put the mouse cursor on any of the grey grid intersections & the "Grid Intersection" snap is shown




- **Left-click (& release)** to confirm the start point

A "rubberband" will appear as you move your mouse cursor to specify the endpoint




The length (L) and local angle will be displayed during the rubberband operation. In addition, the relative distance Δx & Δy to the local UCS will also be shown.

- Press **F2** to enable input of the length (L) of Axis via Dynamic Input System (DIS)
- Press **TAB** to cycle to the following input of angle.





- The related parameter will be locked if a value is entered in the textbox. You can unlock by pressing **ESC** or pressing the lock icon at the right of the text box.


- If a textbox is locked and **F2** or **ENTER** is pressed, DIS will be deactivated. However, rubberband operation now continues with the locked parameter for ease of use.



The left figure shows the length L is locked, so you can freely rotate the Axis without changing the length.

- If both text boxes are locked, pressing **ENTER** will accept the operation, and the candidate point will automatically be picked.
- In either of the text boxes, you can use shortcut notation **Length<Angle** or **DeltaX, DeltaY** (without the need to switch by **TAB**.)





- Holding down the **CTRL** key when the rubber band appears will lock the length & angle increment as defined in **Settings Center** → **ProtaStructure Environment** → **General** → **Angle Step & Length Step** input box.
- After specifying the length or angle, pressing **ENTER** or left-click will accept the endpoint
- Try inserting a **multi-segment axis**  by defining points continuously




- Use **F2**, **TAB**, **ENTER** to define destination points as mentioned earlier
- Pressing **ESC** will cause a smart roll-back. If parameters are locked, the DIS is unlocked, then the operation is canceled. If a pick-continuous command is active, **ESC** will unpick points.
- **Right-click** to end the operation and insert the axis



- You are in axes creation mode when the axis property dialog is shown. **Close** it if you would like to end the creation of an axis. The same sentiment applies to all member properties dialog.
- Insert a curve axis by clicking on the curve axis icon 
- Click on the 1st point and then the 2nd point



- Move the mouse cursor to the 3rd point that will specify the offset length of the curve.
- Left-click to confirm the 3rd point → Curve axis will be created




- Alternatively, hit **F2** to specify the offset length manually.

External Reference Drawing


Note: This section is for information. A DXF drawing is required if you want to try out this feature.

ProtaStructure lets you load external DXF drawings and show them as ghost reference layers under your model. **The External Reference Drawing** button can be found under the **Quick Start** menu.



This tool allows you to assign DXF drawings to different stories. Properties like unit, opacity, scale factor, and offset can be set individually for each imported file. The whole state will be saved along with the project data and restored; the next time the project gets opened.

Important! The referenced DXF files should be intact to restore the external drawing layer next time the project gets loaded.



Add

Click **Add** to select and load a DXF file. The file will be converted into 2D drawing entities inside ProtaStructure directly upon loading. However, it will not be visible until the **Active** box is checked.

Active

This checkbox controls the visibility status of the external drawing.

Unit

Please select the correct unit of the DXF file from the table's unit column right after the file's loading. The drawing will be scaled immediately.

Storey No

The imported file will be assigned to the active story initially. You can use the 'Story No' column to set it to any other level. Only one drawing can be attached to a specific story.

Use Colors

If this field is checked, colors defined in the file will be used; a grayscale drawing is displayed if unchecked.

Opacity


This parameter controls the opacity of the colors. This field applies only if drawing colors are selected to be used.

Scale Factor

This factor scales the whole drawing.

Move & Offset

Click the **Move** button and pick two points on the plan view to move the external drawing. Dynamic Input functionality (hit **F2**) can be used here as well. The offset value between the two picked points will be shown in the **Offset** column of the table.



Import

The selected reference drawing can be imported into the assigned story. In this case, the **Import DXF** interface will be loaded with a pre-defined level and file unit values. The drawing can be imported to the existing model in this mode.

A complete model can be developed from scratch in a controlled environment using the **External Reference Drawing** interface and **Import** option.

For more guidance, e.g. 3D Physical Model & 3D Analytical Model import, kindly refer to Prota Help Center : [IFC and DXF Import Guideline](#)

Orthogonal Axis Generator

Let us now start the new model by creating the required model axes. We will define multiple axes in one go using the **Orthogonal Axis Generator**.


- **Select** all existing axes that you have created → press **Delete** (or right-click → **Delete**)

- Go to the **Modelling** tab > Select **Orthogonal Axis Generator** 

Refer to the bottom status bar; the displayed text tells you how to proceed.

→ Pick the **Reference Point (Lower/Left)** of the Axis Group...

- Pick the **intersection** of any two primary grids near the origin (as shown below)



Direction 1 axes are placed horizontally with alphabetic labels (incremented from bottom to top). **Direction 2** axes are aligned vertically with numeric labels (incremented from left to right).

- Accept all the **default** values in the inputs and click **OK**

Orthogonal Axis Generator

GridInsertion

Reference Point - x: - y:

Insertion Angle:

Dir-1 Axes

Axis Label: Step:

Axis Spacing(s):


Axis Extension Length:

Dir-2 Axes

Axis Label: Step:


Axis Spacing(s):



Axis Extension Length:



Four horizontal and vertical axes with a 5 m spacing will be created.

Columns Creation

- Pick *RC Column* icon 
- Use the default size $b1$ & $b2$ and eccentricity $e2$ & $e2$ is as shown below




$e1$ & $e2$ is measure from the centroid of the column



Section Manager : Allows access other section types such as **circular**, “L”, “T”.




Column End Condition : Columns ends are fixed by default. You can apply hinges to top and/or bottom by clicking successively on this icon.



- Insert columns by clicking on the **intersection of axes**
- Multiple columns can be inserted by **dragging a box** around the intersection of axes


Using the two methods, create **ten** columns at positions shown below.




➤ **Close the column properties.** You finish member creation.

Always close member properties when you finish member creation, otherwise you will be unable to proceed to other functions, such as member selection.

Walls Creation


- Click on the **Wall** icon  & the wall properties will appear
- Use the default wall thickness $b = 250 \text{ mm}$ & $e = 0 \text{ mm}$

The parameters are explained in the diagram below



e is measured from the centerline of the wall to its centroid. $e = 0$ means that the centerline of the wall coincides with the centroid of the wall.


- Insert three walls by simply clicking on the shearwall's start and end



Ext I & J : Slight extension to lengthen the wall should be kept small; less than its width as the extension cannot support any members, such as beams.

Beams Creation

- Click on the **Beam** icon  & the beam properties will appear.



e is measured from the beam's centerline to its sectional area centroid. $e = 0$ means that the beam's centerline coincides with its area centroid.


$e-z$: +ve value raise the beam from the story level, -ve lowers the beam

End Releases: Beam ends are fixed by default. To release forces (N,V,T,M), check the box(s).

- Click successively on this icon  to hinge & release all moments to the left or right end of beam.


- In the beam properties, use the defaults values $b = 250 \text{ mm}$ & $h = 500 \text{ mm}$ (as shown above)
- To create a beam, pick the start and the endpoints by clicking on the **intersection of axes**

Notice that you can continuously create the beams from the previous beam.




- **Right-click** to end the beam insertion after inserting the two beams as shown above

Multiple beams can also be inserted by dragging a box enclosing the area you want to insert beams. Beams will automatically be created between columns and walls.




- Click and drag box enclosing the columns & walls shown above.




Seven (7) new beams will be created.


- Insert the rest of the beams by any method as shown below



Check the folder **Beams** in the **Structure Tree** to ensure you have inserted a total of **18** beams.

We will now insert a **curve beam** in the lower right corner of the model.


- Click on the **curve beam** insertion icon  in the **Beam Properties** dialog
- Click on the intersection of **axes A/3** and then the intersection of **axes B/4** (i.e., start & end of the beam)



Define the apex distance by simply moving the mouse cursor, and the preview of the curve beam in grey will show automatically.

- Press **F2** to define the apex exactly as **-1500 mm** & press **ENTER**

A curve beam will be inserted (segments are automatically created). Check the Structure Tree that you have modeled for a total of **19 beams**.




Beams Creation using dynamic snap points

Note: This section is optional and is not part of the final model, but you might want to try it anyway.


Secondary beams can easily be inserted using dynamic snap points (without creating axes).

- Click the **Beam** icon & place the cursor on the **edge** of the primary beam (avoid the Axis)



Notice that snap points on **0.25L**, **0.33L**, **0.5L**, **0.67L**, **0.75L** will be shown when the cursor is placed on the beam.


- Click on **0.67L** as the start point of the secondary beam.
- Place the cursor on the destination beam




Notice that **0.25L**, **0.33L**, **0.5L**, **0.67L**, **0.75L** & **perpendicular** point will appear

- Select the desired point as the endpoint of the secondary beam & a new beam will be created


Pressing **F2** while the cursor is at any of the snap points will allow input of the exact distance from the start of the beam.



Pressing **the CTRL** key while the cursor is placed on the edge line of the primary beam will expose a distance increment of 100 mm. Left-click to select the desired distance (while still holding down the CTRL key).




The step increment can be set **Building Setout** → **Settings Center** → **ProtaStructure Environment** → **Length Step**.



Handy Tip to adjust the position of columns and beams

You can change the position (eccentricity) of the column and beam by simply selecting it & then pressing keyboard arrow keys to move in the direction you want.




- **Select** column GC1
- **Press** right arrow key → to move the column to the right

The step by which the member is moved can be set in **Building Setout** → **Settings Center** → **ProtaStructure Environment** → **Member Section Eccentricity Step** (by default 25mm).

Load Combinations

Before creating slabs, we need to define the load cases & combinations.

- Go to the **Loading** tab, click **Load Cases and Combinations**



Load Combination Editor

P-Delta Analysis

Apply P-Delta Analysis

Approximate slenderness checks using moment magnification method will not be applied when P-Delta analysis is performed.

Totals

Number of Vertical Load Cases = 0

Number of Lateral Load Cases = 0

Number of Thermal Loading Cases = 0


Number of Stage Construction Load = 0

No	Combination	LL Red	R/C	Steel

Buttons: Add, Delete, Loading Generator, Load Cases, Help F1, OK, Cancel

You can add new load cases manually and then load combinations. However, it's easiest to use the Loading Generator to set up load cases and combinations automatically.

- Pick **Loading Generator** & use the options as shown below and click **OK**



Automatic Loading Editor

Create Different Combinations for Steel Member Design

Use Cracked Sections in All Vertical Load Combinations As Well

V.Load Case = 10

H.Load Case = 4

Vertical Load Combinations | Horizontal Load Combinations

Vertical Load Combinations:

- Define Dead Load Case (G)
- Define Live Load Case (Q)
- Define Pattern Loads Automatically
 - =_ ...
 - ==_ ...
 - ==_ ...
 - ==_ ...
 - =_ ...
- Direction Dependent Pattern Loading
- Define Combinations for Roof Live Load (Qr):
- Define Combinations for Snow Load (S):
- Define Combinations for Rain Load (R):
- Stage Cases G Q
- Create New Combinations for Staged G and Staged Q
- Temperature Loading

Horizontal Load Combinations:

- Seismic Loading
 - G+Q+E
 - 0.9G+E
 - Apply 30% of Other Direction Loading
 - Add Vertical Seismic Case
 - Create All Possible Combinations for Symmetric Results
 - Use Cracked Sections
- Notional Loading **NGx, NQx, NGy, NQy** Use Cracked Sections
- Wind Loading **EN1991-1-4 (2005) - Singapore Annex**
 - Define Separate Negative Load Cases
 - Wind Load μ_0 : 0.6
 - Use Cracked Sections
- Soil Pressure
 - Pressure Direction
 - Dir-X **Positive (+)**
 - Dir-Y **Positive (+)**
 - Define Separate Negative Load Cases
 - Use Cracked Sections


You can choose which combination is used for concrete & steel design separately.

If “Use Cracked Sections” is checked, **Section Stiffness Factors** will be applied for that load case. As shown below, all the load cases and combinations will automatically be generated.

Load Combination Editor																			
P-Delta Analysis										Totals									
<input type="checkbox"/> Apply P-Delta Analysis Approximate slenderness checks using moment magnification method will not be applied when P-Delta analysis is performed.										Number of Vertical Load Cases = 10 Number of Lateral Load Cases = 4 Number of Thermal Loading Cases = 0 Number of Stage Construction Load = 0									
No	Combination	LL Red	R/C	Steel	G	Q	Qp11	Qp12	Qp21	Qp22	Qp31	Qp32	Qp41	Qp42	NGx	NQx	NGy	NQy	
1	G+Q	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.50	0	0	0	0	0	0	0	0	0	0	0	0	0
2	G+Qp1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	0	1.50	0	0	0	0	0	0	0	0	0	0	0	0
3	G+Qp2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	0	0	0	1.50	0	0	0	0	0	0	0	0	0	0
4	G+Qp3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	0	0	0	0	0	1.50	0	0	0	0	0	0	0	0
5	G+Qp4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	0	0	0	0	0	0	0	1.50	0	0	0	0	0	0
6	G+Q+Nx	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.50	0	0	0	0	0	0	0	0	1.00	1.00	0	0	0
7	G+Nx+Q	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.05	0	0	0	0	0	0	0	0	1.00	1.00	0	0	0
8	G+Q-Nx	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.50	0	0	0	0	0	0	0	0	-1.00	-1.00	0	0	0
9	G-Nx+Q	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.05	0	0	0	0	0	0	0	0	-1.00	-1.00	0	0	0
10	G+Q+Ny	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.50	0	0	0	0	0	0	0	0	0	0	1.00	1.00	0
11	G+Ny+Q	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.05	0	0	0	0	0	0	0	0	0	0	1.00	1.00	0
12	G+Q-Ny	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.50	0	0	0	0	0	0	0	0	0	0	-1.00	-1.00	0
13	G-Ny+Q	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.05	0	0	0	0	0	0	0	0	0	0	-1.00	-1.00	0

➤ Pick **OK** to save & close the Load Combination Editor.

Slab Creation


➤ Click on the **Slab** icon  and the slab properties dialog will appear

➤ Click on the **Type** box

All the possible Slab Types will appear in pop up menu.

The slab type 1 to 12 relates the slab edge continuity and is used in the design of the slab reinforced based on the coefficient / yield-line method.

Type 1 to 12 does not affect the slab load calculation on the supporting beams, only the design of slab using coefficient method.

 **One-way slab.** The slab load will only to be transferred to the 2 supporting beams in the direction of the span.

The direction of one-way span must be specified in the

Design Angle input box : Angle:

Label Position icons activate the slab label and control the slab label's position.

Insertion method: By default, "Beam Region" is selected. This means the slab will be inserted within the region bounded by the beams.

➤ Select **Slab Type as 1**


For ease in creating this model, we will initially leave Slab Type as 1 for all slabs. Once they have been created & when we are ready to design the slab, there is a function to automatically set the correct type for each slab (covered later).

➤ Enter the slab thickness $h = 200$ mm and concrete cover = 30 mm

➤ In the **Loads** tab, enter **Service Dead Load = 1.2 kN/m²** and **Imposed Load = 3 kN/m²**

Different types of service dead load can be defined via **Building Setout** → **Slab Additional Loads** library.


- Position the cursor in the region bounded by beams @GL 3, 4, C, D, and left-click to create a slab.



The first slab will be inserted.

The yield line shows the tributary area load this is automatically calculated onto the supporting beams. By default, slab load calculation is done automatically onto supporting beam using yield-line method.

- Create **seven more slabs** to give the layout shown below




Inserting Cantilever Slabs (Type 12)

Note: This section is optional and is not part of the final model.

Cantilever slabs can be inserted by setting Type = 12 in the slab property. They are inserted by three clicks - clockwise or counter-clockwise direction does not matter. Cantilever slabs can span more than one beam or wall.


- Zoom to the top-right corner of the model
- Click on **Slab** icon & choose **Type 12** & enter **h = 150mm**
- Go to **Cantilever** tab → Enter **L-Cant = 1000 mm** (cantilever length)



- Pick the **first** intersection of the Axis to define the start of the cantilever
- Pick a **second** point to define the end of the cantilever
- Move the cursor to the side where it is to be inserted → a grey preview will be shown
- Pick the **third** point to confirm & insert the cantilever

To insert a cantilever slab that does not span the entire length of the beam, we must enter values of **d** & **b-slab** in the cantilever slab properties :

- In Slab Properties, enter **d = 1000 mm** & **b-Slab = 2000 mm**





- Pick the **first** intersection of the Axis to define the start of the cantilever
- Pick a **second** point to determine the end of the cantilever
- Move the cursor to the side where it is to be inserted → a grey preview will be shown
- Pick the **third** point to confirm & insert the cantilever

Polyline Slab/Column Edge

Note: This section is optional and is not part of the final model.

The slab edge line can be used to create irregular slab shapes

- Click **Polyline Slab/Column Edge**  under **Modelling**
- Click continuously to define the edge of the cantilever slab.




The method to draw the edge lines is similar to a multi-segment axis.

- At the last point, **right-click** & pick **Finish** to end the insertion. The slab edge lines will be drawn



- Click on the **Slab** icon → Ensure **Type = 1** is selected
- In the **insertion**, ensure that **Beam Region** is selected.
- Click anywhere within the slab edge line, and a new slab will be created.





For regular cantilever slab, it is recommended to use **Type 12** in slab properties (instead of slab edge lines).

The slab/column edge line also includes **Circle**, **Arc** & **Rectangle** and the ability to convert to a column or slab hole or slab drop. After drawing a closed shape line → Select it → Right-click → Convert to Column or Slab Hole/drop.

Views Creation


The graphical editor supports multiple windows; this allows you to create different views in separate windows. The **Views** tab commands can be used to create new views and to arrange the views.



- Go to **Views** tab → Click **3D Physical Model** 


This command will create a 3D physical model view.

- Click **Tile Vertically** → This will tile the plan and 3D view side by side



You can select & modify existing members or insert new members in the 3D view the same way as the plan view.

Note: Alternatively, you can right-click on **Views** in the Structure Tree or header field of the existing view tabs to create new views.




- **Select** the curve beam in the 3D view. Notice the same member will be selected in the plan view.
- **Right-click** (to access the context menu) → **Properties**
- Change the depth of the beam **h-bot** to **600 mm**
- Click **Update** and **Close** the beam properties


Inserting Storeys & Defining Building Parameters

The final model will be a four-story building. We will now insert the other floors.

- Go to **Building Setout** → **Storeys Operations** dropdown → **Insert story**.



- Alternatively, right-click on **Storey** and pick **Insert Storey**



- Input **Total No. of Storeys = 4** → **OK**

Add Storey

Total No. of Storeys:

To add storeys to the top of the building, enter a number greater than the current total. To insert an intermediate storey, enter a number less than current total.

- When prompted to confirm → **Pick Yes**

This automatically inserts stories 2, 3 & 4. We will now edit the information of the stories.

- Pick **Edit Storey** from the same **Storey** dropdown menu to enter the Edit Storey dialog
- Hold **CTRL** key and multiple select Storey 1, 2 & 3. Then click **“Define selected stories as similar.”**

Edit Storey

Info	Storey	h (mm)	Level (mm)	Label	Description	D1 (mm)	D2 (mm)	Wall1 (k N/m ²)	Wall2 (k N/m ²)	Imp. Load Reduction	Similar Storeys
<input checked="" type="checkbox"/>	1	3000	3000	G		15000	15000	0.00	0.00	0.00	2,3
<input type="checkbox"/>	2	3000	6000	1		15000	15000	0.00	0.00	0.00	1,3
<input type="checkbox"/>	3	3000	9000	2		15000	15000	0.00	0.00	0.00	2,1
<input type="checkbox"/>	4	3000	12000	R		15000	15000	0.00	0.00	0.00	

Imposed Load Reduction

Assume Roof as Normal Storey

Similar Storey

Effective Top Storey No:

No. of Rigid Basements:

1st Storey Bottom Level:

Foundation Depth:

Footing Label:

Footing Description:

Storey Label that defined this floor level.

Storeys 1, 2 & 3 will now be identical. Since we have already inserted members in story 1, these members will be automatically copied to stories 2 and 3. In addition, changes to a particular similar level will be applied automatically to all similar stories.

For storeys to be identical, they must also have the **same storey height**. In an actual project, ST01 is the ground floor & will have a shorter storey height & hence should not be made similar.

- Change the member label under the Labels column as shown above, e.g., “G” for ST01 and “R” for ST04.

ST01 members will be labeled GB1, GC1, etc.

- Click **OK** to exit and notice that the 3D view shows storey 1, 2 & 3 with identical members.

Storey 4 (Roof) has no members, so that we will generate (copy) members to this storey.

- Pick **Generate Storey** from the same **Storey** dropdown

Generate Storey

Source Storey:	Target Storey:
<input type="radio"/> Storey: 1 (+3.00m) <input type="radio"/> Storey: 2 (+6.00m) <input type="radio"/> Storey: 3 (+9.00m) <input type="radio"/> Storey: 4 (+12.00m)	<input checked="" type="radio"/> Storey: 1 (+3.00m) <input type="radio"/> Storey: 2 (+6.00m) <input type="radio"/> Storey: 3 (+9.00m) <input checked="" type="radio"/> Storey: 4 (+12.00m)

Replace Existing Columns, Walls and Beams at the Same Insertion in Target Storey


Member Type to be Generated


<input checked="" type="checkbox"/> Columns	<input checked="" type="checkbox"/> Slab Loads	<input checked="" type="checkbox"/> Slab Openings
<input checked="" type="checkbox"/> Shearwalls	<input checked="" type="checkbox"/> Slabs	<input checked="" type="checkbox"/> Slab Strips
<input checked="" type="checkbox"/> Beams	<input checked="" type="checkbox"/> Ribbed Slabs	<input checked="" type="checkbox"/> Model Lines
<input checked="" type="checkbox"/> Braces	<input checked="" type="checkbox"/> Girts	

Selected Members Only

- Under **Source Storey**, pick **Storey 1** & then select **Storey 4** as **Target Storey**
- Click **OK**, and members will be copied from the ground floor to the roof
- Click **Close** and check that members are indeed created in storey 4
- Switch to show **storey 4** in the plan view by **double-clicking** on storey 4 in the structure tree
- Create a **new slab** with the same properties over the lift core since this is the roof level
- Press **ESC** to deselect all previously selected members
- **Right-click** anywhere on the plan view to expose the context menu
- Select **Member Tables** → **Slab Table**

The slab table allows you to view & change the parameters of the slabs in a group



- Click on the **header q** (live load), and the entire columns will be highlighted
- Click the **Column-wise Edit** icon at the top 
- Enter **0.75 kN/m²** → press **ENTER** (all the slabs live load values will be changed)
- **Close** the Slab Table

Slab Table

All Storeys Member Search Close

Slab	Type	h (mm)	g-self (k N/m ²)	Additional Dead Loads	g-Dead (k N/m ²)	q (k N/m ²)	Concrete Cover (mm)	Angle (Degree)	Label Vertex	Do No
Storey: 4										
RS3	1	200	5.00	Enter Value...	1.20	3.00	30	0.00	0: Center	
RS4	1	200	5.00	Enter Value...	1.20	3.00				
RS5	1	200	5.00	Enter Value...	1.20	3.00				
RS6	1	200	5.00	Enter Value...	1.20	3.00				
RS7	1	200	5.00	Enter Value...	1.20	3.00				
RS8	1	200	5.00	Enter Value...	1.20	3.00				
RS9	1	200	5.00	Enter Value...	1.20	3.00				
RS10	1	200	5.00	Enter Value...	1.20	3.00				
RS11	1	200	5.00	Enter Value...	1.20	3.00				

q (k N/m²)

Wall Loads Library

You can set up pre-defined wall loads and then apply them using a dropdown list when adding the wall loads.

- Go to **Building Setout** → **Partition Wall Loads**

Beam Wall Loads Library

Load Name	Color	Layer Name	Unit Weight (kN/m ³)	Layer Thickness (mm)	Load Value (kN/m ²)
100 Brick Wall - Malaysia	■	Brick	20.00	130	2.60
200 Brick Wall - Malaysia	■				
100 Brick Wall - Singapore	■				
200 Brick Wall - Singapore	■				
300 Brick Wall	■				
External Wall	■				
140 Block Wall	■				
100 Block Wall	■				

Total Load (kN/m²): **2.60**

Defaults wall types are automatically set up, but you can add any new user-defined wall type.


- Choose **Cancel** to exit

We will now insert brick wall loading on the beams in ST01.

- Make the plan view active by clicking on it
- Double click on **ST01** in the structure tree to make it active
- Select the bottom-left most perimeter **beam along with Grid A / 1-2**
- Click **Load Editor** in the **Beam** tab that appears.

Member Load Editor

The load editor of the beam will appear once the load cases and combinations are generated.



1. Load Types

- Click to choose the load type to insert, e.g., point load, full uniform load.
- Self-weight & decomposed slab loads are auto-calculated & cannot be edited.

2. Load Case & Loads Folder & Load Properties

- Choose the load case to insert the loads. Existing loads will be listed for the selected load cases.
- Click on the load name to select it > Right-click will expose menu options to Edit, Cut, Copy or Remove the load.

3. Load Properties

- Enter Label, Direction & Magnitude values for the load to be created.
- Select it in the Loads Folder or Loads diagram > Revise values > Click Update to update an existing load.


4. Loads Diagram

- It displays the graphical representation of the loads, including self-weight & slab loads calculated on beams.
- Existing loads can be selected by left-clicking on the diagram > Right-clicking will expose menu options to Edit, Cut, Copy or Remove the load.
- Click on the beam diagram to insert a load after choosing the **Load Type** & input values in the **Load Properties**.
- The load coordinate system is shown with X, Y, Z arrows. The beam & loads diagram can be rotated by right-clicking & drag.

5. Load Type filter


- Click the Load type icon to toggle on and off the associated diagrams.

6. View Options & Shortcuts



- These settings control the rendering of the member, loads graphics, text height, scaling & frame labels.
- **Show Loads as merged** : Loads under the same load case will be combined in a single diagram. This option must be **switched off** to edit or remove the load.
- **Show Infill Wall as link Load** : If “on” infill wall will be shown as line usual line loads. The infill wall will be rendered with actual height and width if the setting is turned off.

Let us insert a 100 mm preset brick wall load on this beam :



- Pick **Wall Load** under **Load Types** ribbon.
- Notice only the wall load type layer will be active, and all other load types will be switched off
- Ensure **G load case** is selected in the Loads Folder at the left.
- In the Load Properties, Wall Load Library, pick **100 Brick Wall - Singapore**. Note wall height is preset to 3000mm = storey height.
- Place the mouse cursor on the beam & left click to create the load.

The load will be created and added in the diagram & loads folder.

- Press the **ESC** key to finish the wall load insertion process. Click **OK** to save & exit.

Partial wall can be entered by checking selecting **Measurement Type = Distance or Percent** :

- Enter **Start & End Offset**
- Alternatively, check **Define Wall Length Manually**

Wall Opening, e.g. of windows & doors can be inserted by clicking “**Edit Openings**”.

The brick wall load will be rendered in 2D and 3D views. Notice wall load is also copied to a similar storey as expected.


Storey Load Editor

Loads can also be entered for the entire storey, instead of a single member :

- Ensure **ST01** is active & no members are selected (press **ESC** key)
- Go to **Loading** tab > Pick **Load Editor Storey: 1**



The storey load editor is similar to the member's load editor, except that all the members & loads on the active storey are shown. The differences are described below.



1. Load Types

- Surface Loads are loads are area loads that can be applied to slabs and walls
- Self-weight is auto-calculated & cannot be edited.


2. Load Case & Loads Folder

- Choose the load case to insert the loads. Existing loads will be listed for the selected load case.
- **Loads folder** resembles the **Structure Tree**, which organizes loads under member type
- **Show only Loaded Members**: If checked, will omit any members without any loads from listed.
- Expand the folder > Click on the load name to select it > Right-click will expose menu options to Edit, Cut, Copy or Remove the load.

3. Member Filter


- Toggle visibility of member type in the diagram. For example, if the Beam layer is off, then all beams & loads applied to beams will be hidden.

We will now copy the brick wall load to all the perimeter beams.



In View Options : Show Loads as merged is by default deactivated, so that the wall loads are shown separately. Show Infill Wall load as Line Load is by default activated, so wall load is shown as line load, instead of drawn to actual wall height.


- Choose **G load case** in Loads Folder.
- In **Member Filter**, toggle off the Slab layer, so the slab and slab area loads are turned off.
- In **Load Type Filter**, toggle off **uniform load** & **Slab Loads**, to isolate the wall loads
- **Select** partition wall load in the diagram > **Right-click** > **Copy**
- **Multiple select** all the perimeter beams by holding down the **CTRL** while selecting the beams.
- **Right-click** > **Paste** > Check the same wall load is pasted correctly.
- Go to **Load Types** tab > Click **OK**



- Examine the 2D & 3D views to ensure all wall loads are inserted correctly.

Alternatively, wall loads can also be copied in the plan view by the following steps :

- Select beam with wall load inserted
- Right-click > **Copy Loads** > Select the brick wall load > **OK**



The load case & load type panes act as filters for selecting the load name on the right pane.

- Multiple select the perimeter beams where loads are to be pasted (holding **CTRL** key)
- Right-click > **Paste Loads**


Similar steps can be used to delete loads by selecting beams > Right-click > Delete Loads.

Defining Slab Load via Load Editor

You will learn how to insert slab line load.

- Double Click on the **Storey 4** in the structure tree (to make Storey 4 active).
- Select the bottom left-most slab, **4S1** > Click **Load Editor**

A slab load Editor will appear. It is similar to beam load editor but with additional surface loads type.




- Go to **Loading Types** tab > Click **Uniform load**

Note all other load type layers will automatically switch off for clarity.

- In the 3D orientation cube, click on **Top** > view direction will change to top
- Ensure **G load case** is selected
- For **Magnitude (Start) & (End)** > Enter **5 kN/m**

- Pick the **Start point** on the load > Pick the **endpoint** (approximately vertical)

The line load will be created with a default magnitude. To edit the load :




- Press the **ESC** key to end the line load creation mode.
- In the Load Filter, switch off **Area Load** > Area loads will be hidden for clarity
- Select the line **load name** in the load folder or the 3D diagram (rotate the view to suit).
- For **Measurement Type** > Choose **Distance**

The Insertion inputs will show the location & magnitude of the load in table. The X & Y inputs are with reference to the local axis origin

- **Change** the values as shown above > Click **Update** > **OK** to exit the dialog

The line load will also be shown in the model plan & 3D view.




To edit the slab load, you can select the load in plan or 3D view, Right-click > **Properties**.
To delete the slab loads, you can select the load, press **DELETE** key or Right-click > **Delete**.


Defining Slab Load (via plan view)


Slab loads can also be defined on the plan view of modeling.

- Go to **Loading** tab > Click the **Point, Line, and Area Loads** icon 

The slab load properties will appear as shown below.




- Select the **Line Load** icon 
- Define **Angle = 90 degree**, length of line load, **b1 = 2000 mm** and Load values at start and end, **w1 = w2 = 5 kN/m**.
- Pick the **intersection of axes A/1** (reference point)
- Press **F2** to define the relative coordinates. Enter **"2500,2500"** which means $\Delta X = 2500 \text{ mm}$ & $\Delta Y = 2500 \text{ mm}$ as shown below



Alternatively, you click on 2 points to define the start & end of the line load (without specifying Angle & b1)

You can insert a partition wall load by clicking on the dropdown menu under **"Wall"** and select from

- Press **ENTER** & the slab line load will be created.





- **Delete** this line load by selecting it > press the **DELETE** key

You may use the external reference drawing to display the architectural drawing at the back of your model as a guide for creation of members or slab load.

Slab Opening Creation

You will learn how to define the coordinates and size of the Slab Opening.


- In ST04, zoom to slab between GL A-B/2-3.
- Click the **Slab Opening/Drop** icon  in the **Modelling** tab, and the slab opening properties dialog box will appear as the figure below.




The dialog box titled "Slab Opening" contains the following fields and controls:

- b1:** 1000 mm
- b2:** 500 mm
- Type:** Rectangular
- Angle:** [Empty field]
- Drop Region Definition**
- Drop:** [Empty field]
- Fill Load:** [Empty field]
- Update** (green checkmark icon) and **Close** (red X icon) buttons.

- Define the slab opening horizontal length, **b1 = 1000 mm** & vertical width, **b2 = 500 mm**.
- Pick the **intersection of axes A/2** as the reference point of insertion
- Press **F2** to define the relative coordinates
- Enter **1000,1000** which means $\Delta X = 1000$ mm & $\Delta Y = 1000$ mm in the textbox as shown below



- Press **ENTER** & the slab opening will be created




- Click **Close** in the Slab Opening Properties dialog box

Member Re-labelling for Entire Building

The members are labeled automatically in the sequence they are created.

- To re-label the members systematically, go to **Review Tab > Re-label Members**



- Select all **Members** type
- Change all Sort Reference to **Let-Bot --> Right-Top**.

This means that the left-bottommost member will start with number 1.

- Tick **Retain Compatible Labels Between Storeys**.

This setting forces the members at the same position to have the same label across all storeys (e.g., 1C1, 2C1, 3C1 will be at the exact location).

- Click **OK**.

The members will now be re-labeled systematically with label 1, starting with the left bottommost member.

It is a common practice to have vertical member (column & wall) retain the same labels between storeys, whereas this may not be preferred for horizontal member (beam & slab). To achieve this, you can run the re-labelling twice for different member types with **Retain Compatible Labels** checked & then unchecked.

The model is now completed, and we are ready to run the analysis.


Building Analysis


➤ Go to the **Analysis** tab → click **Building Analysis**  → **Pre-Analysis** tab


Building Analysis

Pre-Analysis | Model Options | Analysis | Post-Analysis | Reports

Project Parameters and Loading


 Settings Center


 Loading Combinations


 Wind and Storey Load

Materials (Default)

	Material	Reinforcement Steel Grades
Columns	C30/37	Grade 500 (Type 2)
Shearwalls	C30/37	Grade 500 (Type 2)
	Longitudinal Web Steel	Grade 500 (Type 2)
	Horizontal Web Steel	Grade 500 (Type 2)
Beams	C30/37	Grade 500 (Type 2)
Slabs	C30/37	Grade 500 (Type 2)
Ribbed Slabs	C30/37	Grade 500 (Type 2)
Foundations	C30/37	Grade 500 (Type 2)
Links		Grade 500 (Type 2)

Edit Materials

Unit Weight of Member: 25.00 kN/m3 (Column, Default)

Unit Weight of Blocks: 4.41 kN/m3

Coeff. of Thermal Expansion: 0.00005 1/°C

Building Model will be merged with the FE Foundation Model when Building Analysis is repeated.

Codes:
Eurocode 2 (SG), Eurocode 3 (SG), Eurocode 1 (SG)

? Help F1

X Close


The Pre-Analysis setting is where the main assumptions of the analysis can be defined :

- **Settings Center:** Access settings center to review & modify analysis parameters such as the design code and notional horizontal load
- **Load Combination:** generate, add or modify any load case or load combination sets.
- **Wind and Storey Load:** automatically generate wind loads, review & input any lateral load. Automatically generated lateral loads such as the notional horizontal loads will only be calculated and shown after the analysis.
- **Edit Materials:** review, add, or change the concrete and steel material of the building.


Materials

We will now define the materials for this project via Building analysis > **Pre-Analysis** dialog.


➤ **Pick *Edit Materials***




The materials and reinforcement steel grades are shown for all member types. **Default Material** is used for super-structure floors. A separate **Foundation Floor** category is automatically created for foundation members only.

If a different material is required for a particular storey, a separate material set can be added by picking the  icon. Steel reinforcement grades and diameters are also defined here.

➤ **Pick *Column Concrete Grade* → select *C30/37* → Apply to all members in this storey → OK**




➤ **Pick *Steel Grade* and ensure that *Grade 500 (Type 2)* is selected and applied to all member types**



➤ Click **“Edit...”** next to **Rebar Diameter** & the rebar table will appear

Grade 500 (Type 2) Rebar Table



- In left hand **Filter** pane, tick **Column, Wall, Beam & Slab** to hide diameters of other members
- Tick the **diameters of bars** to be used in the design of those members as shown above. **Generic** is for all other elements, at least 1 rebar must be ticked.
- Click **OK** to close Rebar Table > Click **OK** to close Rebar dialog > **OK** to close Materials dialog.

Load Combinations

We have already generated the cases and load combinations previously, as shown below.

No	Combination	LL Red	R/C	Steel	G	Q	Qp11	Qp12	Qp21	Qp22	Qp31	Qp32	Qp41	Qp42	NGx	NQx	NGy	NQy
1	G+Q	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.50	0	0	0	0	0	0	0	0	0	0	0	0
2	G+Qp1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	0	1.50	0	0	0	0	0	0	0	0	0	0	0
3	G+Qp2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	0	0	0	1.50	0	0	0	0	0	0	0	0	0
4	G+Qp3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	0	0	0	0	0	1.50	0	0	0	0	0	0	0
5	G+Qp4	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	0	0	0	0	0	0	0	1.50	0	0	0	0	0
6	G+Q+Nx	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.50	0	0	0	0	0	0	0	0	1.00	1.00	0	0
7	G+Nx+Q	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.05	0	0	0	0	0	0	0	0	1.00	1.00	0	0
8	G+Q+Nx	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.50	0	0	0	0	0	0	0	0	-1.00	-1.00	0	0
9	G-Nx+Q	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.05	0	0	0	0	0	0	0	0	-1.00	-1.00	0	0
10	G+Q+Ny	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.50	0	0	0	0	0	0	0	0	0	0	1.00	1.00
11	G+Ny+Q	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.05	0	0	0	0	0	0	0	0	0	0	1.00	1.00
12	G+Q-Ny	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.50	0	0	0	0	0	0	0	0	0	0	-1.00	-1.00
13	G-Ny+Q	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1.35	1.05	0	0	0	0	0	0	0	0	0	0	-1.00	-1.00

➤ Review & click **OK** to close the dialog.


Wind and Storey Loads

Allow user to review & input lateral loads such as notional horizontal & wind loads. We will skip this for now.

Wind load cases and combinations must be generated first. For more guidance, kindly refer to Prota Help Center : [Wind and Storey Loads](#)

Building Analysis Model Options

➤ Go to the **Model Options** → **Model** → **Material & Section Effective Stiffness Factors** and review the stiffness factors as shown below.



Building Analysis

Pre-Analysis | Model Options | Analysis | Post-Analysis | Model Export | Reports

Model | ShearWall Model | Slab Model | Settings

Material and Section Effective Stiffness Factors | Default Settings

	Elasticity Modulus	Axial Area		Bending Stiffness	Shear Area	Torsional Constant
Shearwalls (Shell)	1.00	0.50	In Plane	0.50	0.50	1.00
			Out of Plane	0.25	1.00	
Shearwalls (Frame)	1.00	0.50	Major	0.50	0.50	1.00
			Minor	0.50	0.50	
Basement Walls	1.00	0.80	In Plane	0.80	0.50	1.00
			Out of Plane	0.50	1.00	
Slabs	1.00	0.25	In Plane	0.25	0.25	1.00
			Out of Plane	0.25	1.00	
Columns	1.00	1.00		0.70	1.00	1.00
Beams	1.00	1.00		0.35	1.00	0.10
Coupling Beams	1.00	1.00		0.15	1.00	0.10

You can modify the elasticity modulus, section areas, moment of inertias and torsional constants of the member groups to be used in the analysis model. For example, you can enter 0.05 to reduce the moment of inertia values by 95% to reduce the lateral stiffnesses of the columns.

Note: In order to apply these factors, building analysis must be repeated. These factors will be applicable only for load cases for which cracked section properties are used.

The stiffnesses table will only be applied for load cases with **Used Cracked Sections** checked in the respective **Load Case Editor**, except for seismic load cases where cracked sections are always assumed.

All factors can be modified, except those that are greyed out, which must be auto-calculated.

Building analysis must be repeated each time the effective stiffness factors are changed.

To prevent large torsional forces in primary beams due to secondary beams, the global **Torsional Stiffness Factor** is by default set to **0.10** (10%) in the Stiffnesses settings.


Stiffnesses of individual members can be changed by selecting a member → Right-click → **Edit Section/Material** → **Properties** tab.

Running Analysis

- Go to the **Analysis** tab

Before running the analysis, it's always recommended to check the model's validity.

- Click **Building Model Check** & pick **All Storeys** & click **Start**



The building model check will pick up the most obvious modelling errors as indicated.


The warnings / errors are mostly self-explanatory. The exact member(s) affected will be stated.

You should review any warnings / errors and correct the model before proceeding to perform analysis.

Click "**Load Log to Editor**" to open the list of warnings/errors in a separate screen in Notepad for ease of reference.

- Click **Close** to exit the check

The building analysis can now be performed.



- Click **Building Analysis**

Eigenvalues analysis can be done to obtain the natural frequencies and mode shapes of the structure.

The **Batch Design Options** dialog will appear. It allows you to perform the design of column/wall and beams automatically after the analysis. We suggest that this should only be done if you are confident that the analysis result is correct.

- Check **Column/Wall Reinforcement Design**
- Check **Beam Reinforcement Design**
- Pick **Building Analysis** to analyze & design the model

The analysis will also check for instability and large deformations and there will warning messages if any are

The **Analysis Summary Report** will appear at the end of the analysis, summarizing the essential results.

Axial Load Comparison Report

An important check on the validity of the analysis is the **Axial Load Comparison Report**. This report sums all the dead and live load applied at each storey and displays the axial forces in the columns and shear walls. These values need to agree within a tolerance limit of 5%. If they do not, the reason for the discrepancy should be investigated.

- Select **Axial Load Comparison Report** (in the Analysis tab)

Axial Load Comparison Report

TOTAL LOADS (Based On Slabs Loads):

G - Dead Loads:

Storey	Column	Wall	Beam	Slab	Ribbed Slab	Total
4 (+12.00m)	93.75	295.31	291.49	1178.77	0.00	1859.33
3 (+9.00m)	93.75	295.31	741.12	1035.96	0.00	2166.14
2 (+6.00m)	93.75	295.31	741.12	1035.96	0.00	2166.14
1 (+3.00m)	93.75	295.31	741.12	1035.96	0.00	2166.14
Total						8357.76

Q - Live Loads:

Storey	Column	Wall	Beam	Slab	Ribbed Slab	Total
4 (+12.00m)	0.00	0.00	0.00	155.47	0.00	155.47
3 (+9.00m)	0.00	0.00	0.00	546.86	0.00	546.86
2 (+6.00m)	0.00	0.00	0.00	546.86	0.00	546.86
1 (+3.00m)	0.00	0.00	0.00	546.86	0.00	546.86
Total						1798.05

TOTAL LOADS (Decomposed to Beams):

G - Dead Loads:

Storey	Column	Wall	Beam	Slab	Ribbed Slab	Total
4 (+12.00m)	93.75	509.53	1267.13	0.00	0.00	1870.42
3 (+9.00m)	93.75	402.42	1670.86	0.00	0.00	2167.03
2 (+6.00m)	93.75	402.42	1670.86	0.00	0.00	2167.03
1 (+3.00m)	93.75	402.42	1670.86	0.00	0.00	2167.03
Total						8371.50

Q - Live Loads:

Storey	Column	Wall	Beam	Slab	Ribbed Slab	Total
4 (+12.00m)	0.00	28.13	127.34	0.00	0.00	155.47
3 (+9.00m)	0.00	56.25	490.61	0.00	0.00	546.86
2 (+6.00m)	0.00	56.25	490.61	0.00	0.00	546.86
1 (+3.00m)	0.00	56.25	490.61	0.00	0.00	546.86
Total						1798.05

BUILDING ANALYSIS COLUMN AND WALL AXIAL LOADS:

Storey	G	Delta G	Q	Delta Q
4 (+12.00m)	1870.42	1870.42	155.47	155.47
3 (+9.00m)	3975.31	2104.89	702.33	546.86
2 (+6.00m)	6080.20	2104.89	1249.19	546.86
1 (+3.00m)	8185.09	2104.89	1796.05	546.86
Total		8185.09		1796.05

Total Base Reactions: G = 8185.09 kN Q = 1796.05 kN

Table 1: TOTAL LOADS (Based on Slab) is the sum of dead and live loads of all members with the slab load not yet decomposed or calculated on the beam. You can take this as the input weight of the structure.

Table 2: TOTAL LOADS (Decomposition to Beams) considers the decomposition of the slab load onto the beams based on either yield-line or FE Decomposition. The beam load now includes the slab loads (and hence zero values are shown under the slab column).

Table 3: BUILDING ANALYSIS COLUMNS AND WALL AXIAL LOADS sums up the actual column and wall axial loads after building analysis.

Firstly, check **Table 1**. Total values are similar to **Table 2**. This ensures that beams accurately capture all slab loads, i.e., no lost slab loads.


Then verify **Table 2** total values are similar to **Table 3**. This ensures that all the super-structure weight is entirely captured by the columns and walls down to the foundation.

Analytical Model

The **Analytical Model** enables you to review the results of the analysis graphically. It is essential to check & verify the analytical model to ensure the model is correctly set up & results are reasonable.

- Go to the **Post-Analysis** tab of the Building Analysis dialog
- Click **Display Analytical Model**

A new **Analytical Model** tab set will appear with the **Analytical Model** view.




The analytical wireframe is shown in **blue**. Load cases and combinations can be selected on the right-side pane.

If too much information is displayed, the screen can appear cluttered. However, you can create a more meaningful display view by using the various filter buttons and the view settings.

- In the **General** tab, click on the **Filters** command (if it's not activated)

The filter options will appear on the left-hand side of the view. There are options to filter the display by Stores, Axes, and Member Type.




The **Find** command allows you to find a particular Node, Frame, or Shell number.

Connectivity Issues lists all the frames with unsupported nodes and highlights them when selected.

- Click the **Members** tab

This is where you can show node labels, rigid diaphragms, element labels, and beam loads.




- Click **Frame Loads & Frame Load Labels** icons to show loads calculated or decomposed on the beams (& then turn it off).

This may include all the slab loads, brick wall loads, beam self-weight & other manual input loads.

- Click **Diaphragms** → **Select All** will show the rigid diaphragm formed by the slabs (& then turn it off).

The grey lines join nodes constrained by the diaphragm to the center of the diaphragm mass.

- Click on the **Results** tab



- Click **Displacement** → The red lines show the structure's displacement (deflection).


By default, **Auto Scale** is activated. You can deactivate this and then type in your **Scale**.

Displacement Unit can be changed in the **Settings Center** > [Units and Format](#)



- Click on the various **directional displacement** values by selecting **x, y, z & R (Resultant)**. **Rx, Ry, Rz** is the rotation of joints in radians.

The **Maximum** and **Minimum** displacement is shown at the bottom of the screen.

- Click on this **legend** → an arrow will appear to pinpoint the node of maximum displacement.



- Click **Animation** to visualize the deformation of the structure.
- Switch off the **Displacements** display and click on the **Diagrams** button.
- Click on the Axial force **N** icon to display the **Axial Force diagram** (for G Load Case).



Diagrams Legend

N - Axial forces

V2 – Major shear force of beams and walls. Shear of column along dir 1


V3 – Minor shear force of beams and walls. Shear of column along dir 2


M2 – Minor moment of beams and walls. Moment of column along dir 1

M3 – Major moment of beams and

- Experiment with the various effects of the diagrams.

You can change the diagram scale by de-activating **Auto Scale** & typing the **desired Scale**.
 You on/off the diagrams on Column, Shear walls, Beams & Rigid link by clicking on the respective

- Click **Properties** icon  & **select** a frame member will show the detailed member properties, including material, section properties & summary of analysis forces at both members ends.




Frame: 216 Properties	
Frame No	216
Structural Member	RB8 (Beam)
Nodes	
Rigid Zones	
Restraints	
Material Properties	
Section Properties	
I-Section	
J-Section	
Temperature Difference	
Analysis Results ()	
I-End	
N - Axial Force	0.00 kN
V2 - Shear Force 2	-25.97 kN
V3 - Shear Force 3	0.00 kN
T - Torsional Moment	0.00 kN.m
M22 - Bending Moment...	0.00 kN.m
M33 - Bending Moment...	-33.41 kN.m
J-End	
N - Axial Force	0.00 kN

Contours tab will show contour results for shell elements which will only be visible if finite element shell walls is assumed, or floor slabs are selected to be meshed in Building Analysis.

- Go to the **Solid Model** tab.

This allows the various effects such as **Axial Load** & effects to be color-coded on the physical model.




- **Close** the Analytical Model view by clicking on the “x” sign next to the view name.
- Alternatively, you can click to switch to **plan view** Storey: 4 (Plan) and exit the Analytical Model interface.

You must interrogate the Analytical Model and check its validity as that is the actual analytical model from which the design forces will be based.

Column & Wall Design


➤ Navigate to the **Column Section Design** under the **Design** tab

Since we have selected to run column reinforcement design as part of Building Analysis, all the columns and walls are already designed as indicated by a green tick.



Columns	Storey	b1 (mm)	b2 (mm)	Design Status	Utilization Ratio	Print	Qty	Supplied Steel(%)	Steel Bars	Links
GC1	1	500	250	✓	0.42	✓	0	0.64	4x1H13 + 2x1H13	H10-250
2C1	2	500	250	✓	0.61	✓	0	0.64	4x1H13 + 2x1H13	H10-250
3C1	3	500	250	✓	0.66	✓	0	0.64	4x1H13 + 2x1H13	H10-250
RC1	4	500	250	✓	0.73	✓	0	0.64	4x1H13 + 2x1H13	H10-250
GC2	1	500	250	✓	0.47	✓	0	0.64	4x1H13 + 2x1H13	H10-250
2C2	2	500	250	✓	0.37	✓	0	0.64	4x1H13 + 2x1H13	H10-250
3C2	3	500	250	✓	0.33	✓	0	0.64	4x1H13 + 2x1H13	H10-250
RC2	4	500	250	✓	0.41	✓	0	0.64	4x1H13 + 2x1H13	H10-250

If they are not designed, you can choose **Column Design (Batch Mode)** → **Reselect All Bars** to design all columns at one go.

➤ Go to the **Reports** tab → Choose **Design Report** 

A tick in the Print column marks the columns included in the report. Columns can be added or removed from the report by checking or unchecking the **Print** checkbox. Furthermore, icons Mark All Columns and Remove Print Marks can be applied to all columns.

Column Design Results

Report Options

Include All Load Combinations in the Report

Include Interaction Diagram in the Report

Display All Combinations in the Interaction Diagram

Include Column/Wall Sections in the Report

Column Design Report Title:


Column and Wall Design Results Report can be prepared using this dialog.
 The report will contain the members as filtered and sorted in the Column/Wall Design Table

➤ Check “Include Column/Wall Sections in the Report” to draw the column section detail.

You can also give the report a title.

➤ Pick **OK** to generate the report


All reports can be exported in PDF, MS Word, image, or webpage (HTML) format.



➤ **Exit** & this report will automatically be saved & made available for compilation in **Report Manager**

The Interactive Column Design allows you to examine & alter individual column designs in more detail.

➤ **Double click** on **GC1** in the list of columns in the Column Design screen.



Section Dimension shows the parameters of the column such as size, clear height & concrete cover

Steel Bars shows the number and layout of the rebar. These can be changed.

Load Combination table list down all the load combination. The most critical (governing) is highlighted in **red**.

Required & Supplied As are calculated from the critical load combination.


Slenderness tab shows the bracing assumption, calculated effective

If there are changes in the assumption of this column, you can click the **Interactive Design** button to re-perform the reinforcement design.

You can change the dimensions (b1,b2) above & click **Update**. This is handy if a column fails due to insufficient size & you want to try out if a bigger size works. However, due to the change in column size, the weight & stiffness of the model will change. Hence, you should re-run the analysis and re-check the column design to ensure it is sufficient finally.

➤ **Click Column Analysis** to inspect the Interaction Diagrams (capacity curves).

The **Interaction Diagrams (N-M)** show the possible combination of axial force and moment that cause failure to a given column dimension and rebars. This “capacity curve” indicates the maximum axial capacity of a reinforced column is dependent on the co-incident or applied moment (vice versa). The axial capacity of the column decreases as the applied moment increases until the ‘Balance point’, the max moment capacity. After this point, moment capacity decreases with decreasing applied axial load.



➤ **Select Interaction Diagram (N-M)**

For rectangular columns, there will be 2 capacity curves in direction 1 and direction 2 respectively.

The governing design will be the direction with load combinations closer to the curve; for this column in will be along dir-2, the shorter dimension & hence weaker capacity.


➤ **Select Dir-2 (N-M22)**

To verify that this column passes with the rebar selected, all the design combination points must be within the curve, especially if you have manually changed the rebars in Rebar Table.

The **Interaction Diagrams (M22-33)** plots the component directional moment capacity of the column at a given applied axial load.

➤ **Close the Interaction Diagram and go to the Slenderness tab**

The **Slenderness** tab shows the bracing conditions of the column/wall, effective length factors & additional moment (M-add) due to slenderness.



For this column, it is braced in both directions, the calculated effective lengths β are less than 1 & hence M-add is zero or minimal.

You can change the bracing condition manually.

- **Untick both Dir-1-Braced & Dir-2 Braced**
- **Click Interactive Design to refresh the design**
- **Click Design Report for detail report**
- **Go back to Slenderness tab to review**


Notice that the unbraced condition of the column now results in effective lengths > 1 . As a result the additional slenderness moment, ‘Added Moment’ is calculated and auto-added to the base design moment to become the final design moment.

If you want to manually save either the Bracing or β factors, ensure to tick “Edited”. This means the design module will not auto-calculate these values anymore.

- **Click Diagrams to view the shear force, bending moment, or deflection diagrams.**
- **Click Elevation Drawings to view the reinforcement of the column in elevation.**

Manually Specifying Column Design Forces (for info)

The column design forces are automatically linked and updated to the latest analysis run. You can over-write the column design forces manually.




- To manually enter column design forces :
1. Select the first row of column design forces
To select more rows, hold down **CTRL** key
 2. Pick **Select Marked Combination as User Defined**
 3. Click on figures under "N" axial load & enter figures for top and bottom, e.g. 1000,1000
 4. Pick **Select / Unselect All** to select all rows
 5. Click **Interactive Design** to refresh the design
 6. Untick **User Defined Loads** to auto-link back to analysis forces.

Manually Change Column Reinforcement (for info)

The column design module will automatically design the column to pass status. However, there are situations where you might want to specify the reinforcement manually & check if the column passes.

To manually fix the layout & number of rebars & let column design auto-select rebar size :



1. Input "2" for 1-int under Qty column
Notice diagram now shows 2 nos. internal horizontal bars on both sides
2. Pick **Parameters**
3. Pick **Fixed Bar Layout Method** → OK
This option ensures that the number of bars will not change during re-design
4. Click **Interactive Design** to re-design
The column will be re-designed to 8 number of bars as specified. If this reinforcement is insufficient, the program will auto-increase the bar size, say from H13 to H16.

You can also manually change both the number of bars and rebar sizes (i.e., both Qty & Diameter). **Do not** click on **Interactive Design**, which will change the rebar sizes. You must then manually check the following to ensure the column passes :

- Check **As Supplied** is more than **As required** and **Min Steel %**
- Click **Column Analysis** → Check all design points are within the Interaction Diagrams N-M11 & N-M22
- Click **Cancel** to exit the Interactive Column Design dialog and **Close** the window.

Beam Design

- Go to **Design** tab → pick **Storey Beams**

Since we have selected beam reinforcement design as part of Building Analysis, all the beams are already designed as indicated by green ticks.

Group	Axis	Storey	Part	Beam	Quantity	Rebar Pattern	Design	U. Ratio	Print	Beams
	A	1	1	5	1	Standard Pattern 2	✓	0.88	<input checked="" type="checkbox"/>	GB1 - GB2 - GB3 - GB18 - GB19
	B	1	1	3	1	Standard Pattern 2	✓	0.93	<input checked="" type="checkbox"/>	GB4 - GW1 - GB5
	C	1	1	3	1	Standard Pattern 2	✓	0.91	<input checked="" type="checkbox"/>	GB6 - GW2 - GB7
	@1	1	1	1	1	Standard Pattern 2	✓	0.98	<input checked="" type="checkbox"/>	GB8
	D	1	1	2	1	Standard Pattern 2	✓	0.97	<input checked="" type="checkbox"/>	GB9 - GB10

If they are not designed, you can choose **Beam Design (Batch Mode)** to design all beams at one go.

A tick in the Print column marks the beams included in the report. Beams can be added or removed from the report by checking or unchecking the **Print** checkbox.

- Choose **Remove Print Marks** to exclude all beams in the report
- **Check/tick** the checkbox under **Print** for the first-row beam axis A only

Group	Axis	Storey	Part	Beam	Quantity	Rebar Pattern	Design	U. Ratio	Print	Beams
	A	1	1	5	1	Standard Pattern 2	✓	0.88	<input checked="" type="checkbox"/>	GB1 - GB2 - GB3 - GB18 - GB19
	B	1	1	3	1	Standard Pattern 2	✓	0.93	<input type="checkbox"/>	GB4 - GW1 - GB5

- Choose **Design Report**

BEAM DESIGN RESULTS

Report Options

Print Beam Loads

Print Shear Force Diagrams

Print Moment Diagrams

Split Tables (Faster, more pages)

Print Rebar and Axis Image

Beam Design Results Report can be prepared using this dialog.

Report will include only the filtered beam axes in the Beam Design Table.

Select/Deselect All

The Beam Design Report is in rich text format.

Print Beam Loads – List all the loads on the beams in table format. This will significantly increase the size of the report.

Print Shear / Moment Diagrams - Print the envelope shear / moment diagrams in pictures.

Print Rebar and Axis Image – Prints reinforcement design as shown in interactive Reinforcement Data interface. This will significantly increase the size of the report.

- Uncheck **Print Beam Loads**.
- Uncheck **Print Rebar and Axis Image**
- Pick **OK** to generate the report


Beam Reinforcement Design Rev: 1	Prota Asia (21838) Calc. By: Checked By:
-------------------------------------	--

Beam Reinforcement Design

Axis: A Storey: 1

Materials: C30/37 / Grade 500 (Type 2) (Links: Grade 500 (Type 2)) Concrete Cover: 35 mm

Diagrams



Bending

B _w x H (mm)	GB1 L= 5000mm 250 x 500			GB2 L= 5000mm 250 x 500			GB3 L= 7888mm 250 x 500		
Flange B _f x H _f (Left) (Right)	---			---			---		
Top Edge									
M (kN.m)	61.3	0.0	77.6	62.7	8.0	103.5	204.7	19.9	203.0
d (mm)	449	449	449	449	449	449	449	449	449
K/K'	0.24	0.00	0.31	0.25	0.03	0.41	0.81	0.08	0.80

➤ **Exit** & this report will automatically be saved & made available for compilation in **Report Manager**

The Interactive Beam Design allows you to examine individual beam design in more detail

➤ **Double click** on any of the beam axis in the list of beams in the **Beam Design** dialog

Reinforcement Data window shows the details of the beam design.

Required As is shown in blue as is based on design envelope of all load combination.

Extra As shows the additional or surplus area of steel based on selected steel.


s-Bar-CL (Top)/(Bot) shows the spacing of the rebars at the outmost layer.

Deflection Check shows the actual vs allowable span/effective depth. The modification factor is automatically applied.

Rebars designed are shown in the various rows including shear links. These can be manually changed if desired.

Any figures in **red** indicate a failure to meet the design criteria and should be investigated.

➤ Click on the **Diagrams** button to see the loading and design forces.



Loads, Diagrams & Deflections

❖ Display Detailed Values :

- Checked: A tracing window will appear showing the exact values of the diagrams, e.g., shear & moment, when the mouse cursor is placed at a particular location on the member.

❖ Optimize Stations :

- Unchecked: The diagrams are displayed using the default maximum number of stations.
- Checked: The number of stations will be reduced & optimized to maintain similar accuracy.

❖ Diagrams :

- L1/ L2 / L3: Check to show slab loads decomposed & user-defined loads on beams
- N = Axial force ; T = Torsion
- V2 = major shear ; M33 = major moment ; δ_2 = major deflection
- V3 = minor shear; M22 = minor moment ; δ_3 = minor deflection

❖ Deflection Display Types :




Deflections are calculated along the member span for each load case and combination. Deflections can be displayed in three different ways:

- **Absolute:** The absolute rotation and deflection values display the deflected shape.
- **Normalized:** The absolute shape is normalized to the value calculated at the first point.
- **Relative:** The deflected shape is normalized to both start and endpoints. This is particularly useful in determining the deflection relative to both ends in serviceability checks.

Visualization Tools & Report

- ❖ Horizontal Scale → Increase or decrease horizontal Scale of diagrams


- ❖ Default Display Scale → click to reset to the default scale

- ❖ Increase / decrease font size 
 - ❖ Default Font Size  → Click to rest to default font size
 - ❖ Report  → Generate a report in tabular format with/without diagrams.
- *Exit the diagrams & Close the beam design dialog*

The same beam diagrams can be assessed by :

- *Select a beam on plan view → Right-click → Analysis Results Diagram*

The same diagrams are used for columns & walls :

- *Select a column or wall on plan view → Right-click → Analysis Results Diagram*
- *Alternatively, access the Interactive Column Design → pick 'Diagrams'* 


Slab Analysis & Design

For beam/slab models, slab reinforcement can be obtained by inserting slab strips in the X and Y directions. This process uses the moment coefficient method from the tables in BS8110. This is independent of the general building analysis and can be carried out before or after the building analysis.

To use the moment coefficient method, it is essential to set all the **Slab Types** correctly per the tables in BS8110. This can be done automatically in batch mode by right-clicking on the slab icon in the structure tree and choosing **Set Slab Types Automatically**.


➤ From the **Structure Tree**, double click on storey **St: 1** to return to the 1st Storey plan view.

➤ **Right-click on Slab** → **Set Slab Types Automatically** → Choose defaults options → **OK**




Slabs that do not have 4 edges is beyond the scope of the moment coefficient method. It will be entirely up the user to set the appropriate slab type or use alternative finite element method to analyse & design these slabs.


➤ Click **OK** to close the Messages dialog.


➤ Go to the **Modelling** tab & click on the **Slab Strip** 


The Slab Strip Properties will be displayed:

- Slab Strip **Type: Analytical Strip** is used for design based on the Code Method. **FE Strip** is used for innovation based on Finite Element Analysis results. **Manual strip** is used to manually input rebars without any analysis & design.
- The correct “At Start” and “At End” boundary conditions must be specified when drawing the strips. The three options are:

 **Slab** - The Strip starts or ends inside a slab. The bottom steel for the slab in question is not designed, but the span of the slab can be defined, and this value is used in determining the support steel extension.

 **Bob** - The Strip starts or ends beyond an edge beam or wall. The support steel at the edge is bent down into the beam/wall.



 **Cantilever** - The Strip starts or ends beyond a cantilever slab.




- Set the *Dir:* to *X*
- Set the *No:* to '1' so that the strip label is *X1*
- Set *Type* to *Analytical Strip*
- Set the *At Start* condition to *Bob*.
- Set also the *At End* condition to *Bob*.

Pick the slab strip's start point outside the floor plan, as shown below.

- Hold down on the *CTRL* key and then click the end of the strip to the right of *Axis 4*





- Draw another similar slab strip *X2* to obtain the design for the slabs between *Axis B-C/1-2*
- Draw similar slab strip *X3* to obtain the design for the slabs between *Axis B-C/3-4*
- Draw slab strip *X4* to obtain the design for the slabs between *Axis C-D/1-4*



Now draw the **vertical strips** to design Y-direction rebar for the slabs.

- Change the *Dir* to *Y*
- Reset the *No.* to **1** again so that the strip label is *Y1*
- Keep *Type* as *Analytical Strip*
- Keep the *At Start* condition as *Bob*
- Also, keep the *At End* condition as *Bob*
- Draw **4 nos.** of the vertical strip through all of the slabs

The final layout of strips & slab reinforcements should be as shown below.



We can now re-check the strips as a batch and create a slab analysis & design report.

- Go to the *Design* tab → choose *Slab Analysis and Design*


Slab Strip	Storey	Type	Analysis Results Sour...	Slabs	U. Ratio	Design Status	Print	Rebars
X1	1	Span Strip	-	GS2 (h=200 mm) GS3 (h=200 mm) GS1 (h=200 mm)	0.79	✓	☑	21H10-225 + 19H10-250 21H10-225 + 19H10-250 17H10-225 + 20H10-250 + 14H10-250
X2	1	Span Strip	-	GS4 (h=200 mm)	0.79	✓	☑	21H10-225 + 19H10-250 + 19H10-250
X3	1	Span Strip	-	GS5 (h=200 mm)	0.79	✓	☑	21H10-225 + 19H10-250 + 19H10-250
X4	1	Span Strip	-	GS6 (h=200 mm) GS7 (h=200 mm) GS8 (h=200 mm)	0.79	✓	☑	15H10-225 + 13H10-250 21H10-225 + 19H10-250 21H10-225 + 19H10-250 + 19H10-250
Y1	1	Span Strip	-	GS2 (h=200 mm) GS4 (h=200 mm) GS6 (h=200 mm)	0.89	✓	☑	21H10-225 + 16H10-300 21H10-225 + 16H10-300 13H10-225 + 18H10-250 + 10H10-250
Y2	1	Span Strip	-	GS3 (h=200 mm)	0.89	✓	☑	21H10-225 + 16H10-300 + 16H10-300
Y3	1	Span Strip	-	GS7 (h=200 mm)	0.89	✓	☑	21H10-225 + 16H10-300 + 16H10-300
Y4	1	Span Strip	-	GS1 (h=200 mm) GS5 (h=200 mm) GS8 (h=200 mm)	0.89	✓	☑	18H10-225 + 14H10-250 21H10-225 + 16H10-300 21H10-225 + 16H10-300 + 16H10-300

The slab analysis & design dialog will appear with a summary of pass / fail status, utilization ratio & reinforcement. The functions at the top menu bar are :

- ❖ **Interactive Design:** Select a slab strip > Interactive Design will allow access to detail strip design
- ❖ **Slab Strip Design (Batch Mode):** Redesign or re-check the existing design of all strips at once
- ❖ **Check Slab Thickness:** If applicable to the selected code, check the sufficiency of slab thickness.
- ❖ **Settings & Parameter:** Opens up the slab design settings in the Settings Center
- ❖ **Filter:** Allows filter by a storey, slab thickness, and design status
- ❖ **Copy Bars & Paste Bars:** Allow copy & paste of bars of similar slabs marked with = symbol
- ❖ **Design Report:** Prints out the design report

➤ *Click Design Report*

The **Slab Reinforcement Design** report will be displayed. Options are available to configure and then print it. Any failure in the design will be highlighted in the **Notifications** pane at the left.



Slab Analysis and Design

Notation	Definitions
d	Slab's Effective Depth
h	Slab Total Depth
q _{max}	Maximum Load Combination
L ₁	Width of the Slab Along the Strip Direction
L ₂	Width of the Slab Perpendicular to the Strip Direction
C	Moment Coefficient (C = M / (q _u L ₂ ²))
M	Ultimate Moment
A _s	Reinforcement Area

Slab Strip : X1 -- Storey : 1

Materials : C30/37/Grade 500 (Type 2)

Slab	d/h (mm)	q _{max} (kN/m ²)	L ₁ (mm)	Support C/M	Span C/M	M _{Left} (kN.m)	As-Left Required (mm ²)	As-Span Required (mm ²)	As-Right Required (mm ²)	Left-Support Straight	Span Bars BentUp Straight	Right-Support Straight
GS2	165200 0	12.87 1.35G + 1.5Q	5000 4750	0.0450 13.1	0.0340 9.9	1.5 13.1	249 314	249 349	249 314	H10-250 (T)	H10-225 (B)	H10-250 (T)
GS3	165200 0	12.87 1.35G + 1.5Q	5000 4750	0.0450 13.1	0.0340 9.9	13.1 11.5	249 314	249 349	249 314	H10-250 (T)	H10-225 (B)	H10-250 (T)
GS1	165200 0	12.87 1.35G + 1.5Q	4331 4273	0.0341 8.0	0.0261 6.1	11.5 0.9	249 314	249 349	249 314	H10-250 (T)	H10-225 (B)	H10-250 (T)

Deflection Check


Slab	L/d _{minimum}	s	Status

➤ *Review the report and then Exit*

Design Status

The design status can be displayed graphically in the plan or 3D window.

- Click on the **3D view** to make it active
- Go to **Review Tab** → pick **Design Status** → **OK**




Quantity Extraction Tables

The concrete and Formwork quantity reports can be produced.

➤ Go to the **Drawings & Reports** tab → Pick **Quantity Extraction Tables**

➤ Choose **Concrete Quantity Extractions Table** → click **Calculate**

As shown below, this produces a concrete quantity report with member type and storey breakdown.



The dialog box shows the 'Report Format' set to 'ProtaStructure Report' and 'Concrete Quantity Extractions Table' selected. The 'Calculate' button is visible.

Storey	Beam	Column	Slab	Rib Slab	Blocks	Foundations
Foundation	0.00	5.71	0.00	0.00	0.00	0.00
1	10.76	15.56	32.69	0.00	0.00	0.00
2	10.76	15.56	32.69	0.00	0.00	0.00
3	10.76	15.56	32.69	0.00	0.00	0.00
4	10.76	15.56	37.20	0.00	0.00	0.00
Total	43.03	67.96	135.27	0.00	0.00	0.00

Total Concrete: **246.25 m3**


➤ Click **Report** to produce a detailed report

Project Preferences

The Project Preferences dialog allows you to enter the details of the project model.

➤ Go to **Building Setout** tab → Click on **Settings Center** → **Project Preferences** → **Header**

Options



The 'Title' tab is selected in the left sidebar. The main area shows project details:

Licence: **Prota Asia (21838)**

Consultant	
Calculated by:	#designed_by
Controlled by:	#checked_by
Drawn by:	#drawn_by
Presented by:	#presented_by

Project	
Client Name:	#client_name
Project Title:	#project_title
Project No:	#project_no
Project Date:	#date
Project Address:	#project_address
Revision No:	#rev_no

Title - Enter the Consultant and Project details to be displayed in the header of all the reports.

Statistics - Show graphical chart of essential model information such as the total number of members, members types, grids & storeys. In addition, it shows the number and types of foundation, beam & column end releases. A text file can be created.


Notes - Enter additional information on this model, such as revision changes, etc.

➤ Key in the various information in the **Title** tab as desired

Report Manager






The **Report Manager** is the central report manager where all analysis and design reports can be accessed and managed.

➤ Go to the **Drawings & Reports** tab → choose **Report Manager** 



- **Report Sets** (left): This shows the constituent reports, which will be compiled & combined into a single final report.
- **Reports Repository** (middle): All the individual reports generated and available to be included as a Report Set.
- **Notifications** (right): Important notes and warnings from the model's analysis are shown for easy reference.


You can expand or collapse the main folder by clicking on topic icons. To create a combined report :


- Select **New**  in the **Report Sets** tab and give the new report set a name
- Select **Add All Available**  reports in the **Reports** window to include only available and generated reports in the report repository.
Alternatively, click and drag a report from the **Reports Repository** into the report Sets pane.
- Choose to insert **Table of Contents**  and **Summary Report**  using icons below the report Sets tab.
- Select **View**  to generate and view the report set.


Other useful functions include loading of company logo : **Load Logo** , inserting **QR Code**  & inserting external .doc or .rtf files : **New Report from File** .

Steel Model

We will now start a new steel model. This section will cover steel members, trusses modeling, analysis & design. The below is the screenshot of the completed model, which can also be found in the default Project Data folder.




- Click **New Project**  and type the project name as shown using the ‘_’ character for spaces.




- Select **Singapore (Eurocode)** template and then **OK**

Axis Creating & Storey Insertion

- Go to Modelling tab → Pick **Orthogonal Axis Generator** in the **Modelling** tab
- Pick the **intersection** of the primary grid near the origin (5000,5000 coordinate)
- In Orthogonal Axis Generator, change **Dir-2 Axis Spacing** to **5000*2** & click **OK**




- Right-click on **Storeys** in the Structure Tree and pick **Add new Storey**



- Input **Total No. of Storeys = 2** → **OK**
- When prompted to confirm → Pick **Yes** → The plan view will now change focus to Storey 2

Materials & Load Case / Combination Generator


- Go to **Analysis** tab → **Building Analysis** → **Pre-Analysis** tab
- Pick **Edit Materials** → Change the steel grade of all members to **S355** (as shown below)




The global materials grade of the truss, purlins, girts & brace members are shown & can be changed. Individual member material can also be changed in their respective **Section Manager** dialog by selecting the member → Right-click → **Edit Section / Material**.

We will now auto-generate the load cases and combination (required to add roof purlins loads).

- Pick **Loading Combination** to access the Load Combination Editor



- Pick **Loading Generator** → Pick the options as shown below → click **OK**




- Load cases & combinations will be generated. Pick **OK** & **Close** the building analysis menu.

Steel Columns Creation

- Click on **Steel Column**

in the **Modelling** tab.



- In **Column Properties**, change **Len (Storey)** to 2

This means the column will span 2 storeys with effective length of 2 storey height. Thus, we do not need to model any column in ST01.

- Change the **Angle** of rotation to **90 degrees**


This will rotate the steel section 90 degrees on plan view.

- Pick **Section Manager** icon

This will launch the **Section Manager** dialog which allows us to pick a section profile.

- **Column End Condition** : Columns ends are fixed by default. You can apply hinges to top and/or bottom by clicking successively on this icon.

Column Steel (UC 300x200x93)




- In **Section Manager** dialog, pick **Singapore**

This will access to Singapore Steel Profiles (Continental)


- Pick **UB 250x250x67** → **Select**

- Pick **OK** to close the dialog

- Enter **eight nos** of columns along **Axis 1/A-D & 3/A-D**



- Right-click on **Views** in the Structure Tree and pick **3D Physical Model**.







This command will create a separate window showing the 3D view.

- Go to **Views** tab → **Tile Vertical**

This command will arrange the 3D view and plan view in 2 windows.

- Click on the **Plan** view to make it active (the active view title & border will be darker)
- Double-click on **Storey 1** in the **Structure Tree** to switch focus to Storey 1




- Click on the **Steel Column** icon 
- Change **Len (Storey)** to **1** in **Column Properties**
This property means that the column will only span a single storey. The columns with "Len = 2" are grey in ST01 because they were inserted in ST02.
- Ensure the **angle** of rotation is **90 degrees**
- Pick **Section Manager** icon 
- Ensure that the same **UB 250x250x67** is selected.
- Insert **three** nos. of the column along **GL2/B to D**.

Check the **3D view** to ensure the columns were properly


Steel Beams Creation

- Click on the **3D view** to make it active (the active view title & border will be darker)
- Double-click on **Storey 1** in the **Structure Tree** to switch focus to Storey 1.
Notice the grids will move to storey 1. This operation ensures beams to be created in St: 1 in the 3D view.
- Click on **Steel Beam** icon
- Click on **Section Manager** in Beam Properties




- In **Section Manager** dialog, pick **Singapore flag**
This will access to Singapore Steel Profiles (Continental)
- Pick **UB 250x125x25** → **Select**
- Pick **OK** to close the dialog


- **End Releases:** Click successively to **hinge** both ends of the beam
- Click on the **3D view** to make it active > **Double-click** on **St: 1** to make it the active storey.
- In the **3D view**, create **seven nos.** of beams in the region bounded by **GL B, D,2 & 3** (as shown below)



- Go to the **plan view** of **ST01** → Create **four nos.** of **UB 200x150x30** secondary beams in the region bounded by **GL B, D,2 & 3** (as shown below)
- Ensure both ends of the beams are hinged **End Releases:**



Use smart points to create secondary beam. With beam properties out, place the mouse cursor at the edge of the primary beam (not center) & the smart points will appear at $0.25L$, $0.33L$, $0.5L$ & $0.75L$.


Use **Beams Sections**  in the **Review** tab to show beams of different sizes by color. Assign colors to members in **Section Manager** dialog → **Material Color**

Steel Truss Creation

We will now insert roof trusses. Trusses are best inserted using the 3D view.

➤ Go to the **3D view** → Double-click on **St: 2** in Structure Tree to make it **active** & grids are at **St: 2**

➤ Click on the **Truss** icon 




➤ Pick **grid intersections A/1** to define the **start** of the truss.


A dynamic rubberband will appear with the default truss type if no truss is defined before.

➤ Pick **grid intersections A/3** to define the **end** of the truss.

After you pick the second point, the truss generator dialog will appear.




- In *Geometry*, pick *Duo-Pitched* truss → Change *Truss Support Placement* to *Top chord*
- Change *Apex height* to *1500 mm*, *Left & Right Heel height* to *800 mm*
- Click on the *Members* tab



- Change the truss member sections to the following by click on the section name :
 - Top & bottom chord = **RHS 150x75x3** (Singapore)
 - Diagonals & Verticals = **SHS 75x75x3** (Singapore)
- Click **OK** to exit the *Truss Generator* dialog.

The truss will be inserted. The truss insertion will automatically switch into copy mode & you can pick the next point of insertion.




- Insert **3 nos.** of similar trusses by clicking grid intersection **B/1, C/1 & D/1**
- Press **ESC** or **Right-Click** to end the copy operation


To enter copy mode manually, select the truss → Right-click → Pick Copy

- Select the basepoint @ intersection of **A/1**
- Insert **3 nos.** of similar trusses by clicking grid intersection **B/1, C/1 & D/1**


Purlins Creation

We will now insert purlins on the roof trusses. Purlins are best inserted using the 3D view.


- Click on **Purlin** toolbar button 
- Select the **first truss @ GL A** → Select the **last truss @ GL D** (Intermediate trusses will be automatically found)
- On **Purlin Dialog**, you can specify the following:
 - Profile / Section of the for the Purlin
 - Section Alignment: On the Section / Under the Section / Center
 - Generation Method: By Truss Joints / By Spacing
 - There are many other options. Refer to the diagrams as a guide.
 - The 3D diagram on the right can be rotated (right-click & drag) & zoom in/out (mouse wheel)



- Choose section **UPN100** (under **Steel** → **European sections** → **UPN**)



- In the **Sag Rods** dialog → **Insertion Method** → Choose **None** to remove all sag rods (for simplicity)



- Pick **OK** to exit the purlins dialog.


We will insert the roof loading using the more specific Cladding function.

Creating Cladding & Loads

- Go to **Modelling** tab → Pick **Cladding** → Select any purlin

The Cladding dialog will appear to insert roof loads on the purlins.

In the **Geometry** dialog, the cladding geometry can be adjusted by selecting the point and changing the values in the vertical and horizontal direction.




- Click **OK** to exit the cladding dialog > The cladding will be rendered on top of the purlins.


- Go to the **Structure Tree** > **Cladding** > Select the cladding label



- **Right-click** > Pick **Edit Loads**


The load editor dialog will appear, which allows you to insert area load on the cladding.




- At the top, pick **Full Uniform Area Load**
- Pick **G Load Case** in the left pane
- In **Load Properties**, ensure **Load Direction = Gravity & Magnitude = 0.5 kN/m²**
- Click & drag window over the entire roof cladding to apply all panels
- Pick **Qr Load Case (Roof Live)** in the left pane & **Full Uniform Area Load**
- In **Load Properties**, ensure **Load Direction = Gravity & Magnitude = 0.7 kN/m²**
- Click & drag window over the entire roof cladding to apply all panels
- Click **OK** to save & exit the load dialog
- You can switch off the **cladding Layer**  by going to the **Display** tab > **Layers**.
This operation will make the view less cluttered & make the selection of other members easier.


Braces Creation

We will now insert some bracings between steel columns.


- Click on the **Brace** toolbar icon 
- Pick two adjacent columns at **A/1 & B/1** → **Brace Dialog** will appear




- In the Brace dialog, you can specify the following:
 - Profile / Section of the for the braces
 - Brace Type (Diagonal, X Brace, Y Brace or K Brace)
 - Alignment & Top/Bot Offsets
 - Apply to analysis: offsets will affect the analytical model
- Accept all defaults & click **OK**
- Insert the same bracing between columns **A/3** & **B/3**
- Check the braces are correctly inserted, as shown below



- Insert new brace between columns **C/3** & **D/3**



- Change **Brace Type** to **Diagonal**
- Input **J End y-Offset** = 3000 mm (rest remains 0 mm)
- Tick **Apply To Analysis: J End Offsets**
This option will ensure the analysis frame will accurately consider this offset.
- Click **OK** → **Diagonal Brace** will be inserted
- Insert another new diagonal brace between the same columns **C/3** & **D/3**




- Ensure **Brace Type** = **Diagonal**
- Tick **Invert** → this will invert the diagonal
- The input **I End y-Offset** = 3000 mm (rest remains 0 mm)
- Tick **Apply To Analysis: I & J End Offsets**

This option will ensure the analysis frame will accurately consider this offset.

- Click **OK** → A new diagonal brace will be inserted
- Check the braces are correctly created in the 3D view as below.


Horizontal braces can also be inserted between beams. Create three horizontal braces connecting the beams in ST01, as shown below.



- Pick 2 adjacent beams
- In the Brace dialog, pick **Brace Type = Diagonal**
- Tick / Untick **Invert** as required by verifying the right-side brace diagram.
- Ensure all **I & J End Offsets = 0**
- Click **OK**
- Check the brace is correctly created as shown in the left figure.
- Repeat the same steps to create total of **3** horizontal braces as shown in the figure.


Girts Creation

We will now insert some girts between steel columns.

- Click on **Girt** toolbar button 
- Select the **first column** at grid **A/3** → Select the **last column** at grid **D/3**.

Intermediate columns will be automatically found.


- In the **Geometry** dialog, you can specify the following:
 - Profile / Section of the Girt
 - Section Alignment: Under The Section / On The Section
 - Spacing, Delete Bottom / Top Member, Left / Right Cantilever, Offsets




- Ensure Profile is **UPN100** (under **Steel** → **European sections** → **UPN**)
- Ensure **Section Alignment** is **On The Section**
- Tick “**Delete Bottom Member**” so that bottommost Girt is removed.

In the **Sag Rods** dialog, you can specify the configuration of the sag rods. For simplicity, we will not insert the sag rods for this model, as there are minor elements.

- In the **Sag Rods** dialog → **Insertion Method** → Choose **None** to remove all sag rods




- Click **OK**, and the girts will be inserted.
- Insert similar girts between columns **A/1** & **C/1** but **Section Alignment** = **Under the Section**
- Check the girts are inserted correctly at both sides of the building, as shown below



Loads can be applied to girds similar to Purlin by creating a cladding first. For simplicity, we skip this.

Column Splice Creation



- Press **ESC** to deselect all members
- Select the corner **column** at **GL D/3**
- **Right-click** → **Define Splice**
- Pick **Add New Splice** in **Splice Location Definitions**
- In **Member Splice Definition** choose :
 - Reference Storey = 1
 - Splice Distance (from floor level) = **800** mm
 - Splice width = **500**mm
- Click **OK**
The splice will be created & listed in Splice Location Definitions.
- **Close Splice dialog**

Building Analysis

- Go to the **Analysis tab** → Pick **Building Analysis**
- In **Batch Design Options**, choose not the design any members → click **Building Analysis**


Once analysis is completed, the **Analytical Model** view will open automatically.

- **Review the results** in the **Analytical Model** view to your satisfaction as outlined in previous section.

For example, check if the roof cladding loads have been correctly considered by switching on the **Frame Loads & Frame Load Labels**.


Steel Design

Steel member design commands can be accessed via the **Design** tab



➤ Go to **Design** tab → **Design All** → Pick **Steel Member Design Check** → **OK**

- ❖ This will check all the adequacy of assigned all steel members in one go.
- ❖ The program does not automatically select the smallest section size.
- ❖ If the model is large, it is recommended to perform design check by member types separately.
- ❖ To access a summary of member design check, **select** the steel member icons in the steel group.

➤ Pick steel **Column Design**  to access the design summary of all steel columns.

Steel Column Design										
Member Label	Storey	Print	Section	Material	Section Class	Slenderness Ratio (k _L /r)	Utilization Ratio	Design Status	Governing Check	
2C1	2	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	95 < 200	0.04 < 1.00	Pass ✓	(Combined)	
2C2	2	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	95 < 200	0.11 < 1.00	Pass ✓	(Combined)	
2C3	2	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	95 < 200	0.11 < 1.00	Pass ✓	(Combined)	
2C4	2	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	95 < 200	0.05 < 1.00	Pass ✓	(Combined)	
2C5	2	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	48 < 200	0.03 < 1.00	Pass ✓	(Combined)	
2C6	2	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	48 < 200	0.09 < 1.00	Pass ✓	(Combined)	
2C7	2	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	48 < 200	0.08 < 1.00	Pass ✓	(Combined)	
2C8	2	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	95 < 200	0.04 < 1.00	Pass ✓	(Combined)	
1C8	1	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	48 < 200	0.01 < 1.00	Pass ✓	(Combined)	
1C9	1	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	48 < 200	0.02 < 1.00	Pass ✓	(Combined)	
1C10	1	<input checked="" type="checkbox"/>	UB 250x250x67	S355	Class1	48 < 200	0.02 < 1.00	Pass ✓	(Combined)	

Total number of members: 11

➤ **Double-click** on any column to review the detailed design checks.


Steel Column Design - 2C1 (UB 250x250x67)

Check Design
 Change Section
 Design Report
 Show Design Stations
 Show Diagrams

OK
 Cancel

Design Summary

Parameters



Section	UB 250x250x67
Section Width	249 mm
Section Height	248 mm
Flange Thickness	13 mm
Web Thickness	8 mm
Section Area	0.0085 m ²
Shear Area 1	0.0065 m ²
Shear Area 2	0.0020 m ²
Torsional Constant	4.670E-07 m ⁴
Moment of Inertia 11	9.931E-05 m ⁴
Moment of Inertia 22	3.348E-05 m ⁴
Radius of Gyration 11	108 mm
Radius of Gyration 22	63 mm
Elastic Section Modulus 11	8.010E-04 m ³
Elastic Section Modulus 22	2.690E-04 m ³

General Parameters

Design Code: Eurocode 3 (SG)
 Partial Resistance Factors: $\gamma_{M0} = 1.00$ $\gamma_{M1} = 1.00$ $\gamma_{M2} = 1.00$
 Effective Length: $K_x = 1.00$ $K_y = 1.00$ $L_x = 6000$ mm $L_y = 6000$ mm $L_b = 6000$ mm

Section Classification

Section Class: **Class1**
[Calculation Details](#)

Check for Combined Forces

Utilization Ratio: **0.044 < 1.00 ✓** (G+Q+Nx) 6.2.1 (7)
[Calculation Details](#)

	<u>N_{ed}</u> (kN)	<u>N_{c,Rd}</u> (kN)	<u>N_{p,Rd}</u> (kN)	<u>U_{Ratio}</u>
Axial Compression:	27.97	3006.76 (CR)	3006.76	0.009

	<u>Curve</u>	<u>a</u>	<u>N_{cr}</u> (kN)	<u>λ_{-bar}</u>	<u>φ</u> (Phi)	<u>χ</u> (Chi)	<u>N_{b,Rd}</u> (kN)
Buckling Major (y-y):	b	0.34	5613.59	0.73	0.00	1.00	3006.76
Buckling Minor (z-z):	c	0.49	1892.49	1.26	0.00	1.00	3006.76

	<u>M_{ed}</u> (kNm)	<u>M_{c,Rd}</u> (kNm)	<u>M_{n,Rd}</u> (kNm)	<u>M_{p,Rd}</u> (kNm)	<u>M_{b,Rd}</u> (kNm)	<u>M_{cr}</u> (kNm)	<u>U_{Ratio}</u>
Bending Major (y-y):	7.49	228.49 (LTB)	313.47	313.47	228.49	345.91	0.033
Bending Minor (z-z):	0.28	144.84 (Y)	144.84	144.84			0.002

Lateral Buckling (LTB): Curve = b $\alpha_{LT} = 0.34$ $\lambda_{bar-LT} = 0.95$ $\phi_{LT} = 0.93$ $\chi_{LT} = 0.73$ $C1 = 1.00$

Interaction Factors: $k_{yy} = 1.01$ $k_{yz} = 0.73$ $k_{zy} = 0.52$ $k_{zz} = 1.03$

Axial Compression Check

Utilization Ratio: **0.011 < 1.00 ✓** (G+Q+Nx)
[Calculation Details](#)

- Click on the **triangle** next to the title check to drill down to more details
- **Check Design** → Re-check the design of this column
- **Change Section** → Allow you to pick another section → New section will be checked automatically for pass/fail.
- **Design Report** → Prepare the design report
- **Show Design Stations** → List out all the design forces of all load combinations
- **Show Diagrams** → Show design force diagrams for load cases, load combinations & envelope
- **Parameters Tab > Buckling** → Input Braced length, Buckling Length Coefficient, Lateral Torsional Buckling length
- **Parameters Tab > Deflection** → Manually edit deflection limits

Effective lengths are automatically detected & calculated by the program based on restraints provided by connected members. You can change them if you wish.

Design Summary

Parameters

Buckling

Deflection

Manually edit the buckling parameters

Braced Length Major, L_x: mm

Braced Length Minor, L_y: mm

Buckling Length Coefficient Major, K_x:

Buckling Length Coefficient Minor, K_y:

Distance between transverse stiffeners: mm

Lateral Torsional Buckling Length, L_b: mm

Set the related field to '0' (Zero), to use the automatically calculated values

- Go to the **Parameter** tab
- Tick **Manually edit buckling parameters**
- Input various **Braced Length**
 - ❖ '0' (Zero) means auto-calculate values. Hence, only input values to over-write them.
 - ❖ It is highly recommended you review the auto-calculated values and amend to suit your design assumptions.
- Go back to **Design Summary** to check the design
 - ❖ Deflection limits can be modified using similar steps.

- Pick **OK** to close the column design dialog
- Pick **Trusses** to design the trusses

Steel Truss Design

Check Selected

Check All

Mark all for print

Remove all print marks


Design Report

Close

Drag a column header here to group by that column

Member Label	Storey	Print	Section	Material	Section Class	Slenderness Ratio (l _d /r)	Utilization Ratio	Design Status	Governing Check
2T1	2	<input checked="" type="checkbox"/>	RHS 150x75x3	S355	Class1	315 > 200	0.41	Pass ✓	(Combined)
2T2	2	<input type="checkbox"/>	RHS 150x75x3	S355	Class1	315 > 200	1.06	Fail X	(Combined)
2T3	2	<input type="checkbox"/>	RHS 150x75x3	S355	Class1	315 > 200	1.08	Fail X	(Combined)
2T4	2	<input checked="" type="checkbox"/>	RHS 150x75x3	S355	Class1	315 > 200	0.43	Pass ✓	(Combined)

- Double-click on the truss **2T2** to access the detailed steel truss design




- **Reset View** → Reset the truss diagram to the original orientation.
- **Show Label** → Reset the truss diagram to the original orientation.
- **Show Utilization Ratios** → Show Utilization ratio for each member.
- ❖ **Pass / Failed** members are shown clearly in **Green / Red**
- ❖ Slenderness Ratio failure will not result in FAIL status as it is not a critical criterion (more a warning)
- ❖ Fail members (UR > 1) will be colored red in the truss diagram.
- ❖ The selected member in the table will be colored **purple** in the truss diagram.
- ❖ The truss diagram at the bottom can be zoomed (mouse wheel) & rotated (right-click & drag).
- **Double-click** on the failed bottom chord member → This will bring up detailed member design

Steel Bottom Chord Design - BC14 (RHS 150x75x3)

Check Design
 Design Report
 Show Design Stations
 Show Diagrams

OK
 Cancel

Design Summary



Section	RHS 150x75x3
Section Width	75 mm
Section Height	150 mm
Wall Thickness	3 mm

General Parameters

Design Code: Eurocode 3 (SG)

Partial Resistance Factors: $\gamma_{M0} = 1.00$ $\gamma_{M1} = 1.00$ $\gamma_{M2} = 1.00$

Effective Length: $K_x = 1.00$ $K_y = 1.00$ $L_x = 1668 \text{ mm}$ $L_y = 10000 \text{ mm}$ $L_b = 10000 \text{ mm}$

Section Classification

Section Class: **Class1**

[Calculation Details](#)

Check for Combined Forces

Utilization Ratio: **1.056 \geq 1.00 X** (G+Q+Qr+Nx) 6.3.3(4)-6.61

[Calculation Details](#)


Axial Compression Check

Utilization Ratio: **1.054 \geq 1.00 X** (G+Q+Qr+Nx)

[Calculation Details](#)

This bottom member fails in **Axial Compression Check & Combined Forces Check**. You can increase the section size or thickness to solve the failure. However, before doing that, let us review effective design lengths. In the results, **General Parameter**, notice that for bottom chord, $L_x = 1668 \text{ mm}$ & $L_y = 10,000 \text{ mm}$.

- L_x is the **Major Braced Length** is auto determined = truss panel length
- L_y is the **Minor Braced Length** is the entire length of the bottom chord between supports



To reduce the minor bracing lengths bottom chord, you can add bracing members at intermediate locations joining bottom chords of the adjacent truss.

Alternatively, go to the **parameter > Buckling** tab to manually edit the bracing lengths.

- If there is a bracing member at the mid-span of the bottom chord, you can change the braced length Minor, L_y & Lateral Torsional Buckling Length, L_b to 5000mm
- Click on **Design Summary**, and the member will automatically be re-checked & result in a pass

The assumption of top chord is :

- L_x is the **Major Braced Length** is auto determined = truss panel length
- L_y is the **Minor Braced Length** is auto determined = purlin spacing


You may want to check the steel beam design. The design interface is similar to the column design.


Design Status & Design Utilization


We can view **Steel Design Status** and **Steel Design Utilization** to review pass/failure status & design efficiency quickly.


The design status can be displayed graphically in the plan or 3D window

➤ Click on the **3D view** to make it active

➤ Go to the **Review Tab** and pick **Design Status**  → OK



➤ Click **Visual Interrogation**  & choose **Steel Design Utilization Ratios** → OK



Closing Summary

Congratulations! You have created your first model in **ProtaStructure**.

We have created, analyzed, and designed a simple small model in this basic training guide. The guidance provided here will give you the necessary knowledge to proceed to an actual project.

For more help and guidance, please refer to **Prota Help Center**: <https://support.protasoftware.com>

We recommend you read the **What's New** document for details of new features & enhancements.

The detail drawings of all the members and the general arrangement drawings can be automatically produced and managed in **ProtaDetails** (concrete) & **ProtaSteel** (steel). We recommend you proceed to read the **ProtaDetails** & **ProtaSteel** Quick Start Guide as the next step.

Should you have any technical support requests or questions, please do not hesitate to contact us at all times through globalsupport@protasoftware.com or asiасupport@protasoftware.com (Asia Pacific).

Our dedicated online support center is available to help you get the most out of Prota's technology solutions with our responsive technical support team.

